

**ECU-DIESEL**

**0000-00**

**INDEX**

**ECU-DIESEL**

## **DIAGNOSIS**

1. ECU-DIESEL.....	3
--------------------	---



**ECU-DIESEL****0000-00****DIAGNOSIS****1. ECU-DIESEL**

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0100	Air Mass Flow (HFM) Malfunction	<ul style="list-style-type: none"> <li>- The external power supply is faulty.           <ul style="list-style-type: none"> <li>• Check the external power supply.</li> <li>• Check the sensor wiring harness (open, short, poor contact).</li> </ul> </li> <li>- Actual air mass flow vs. Output voltages.           <ul style="list-style-type: none"> <li>• -20 Kg/h: 0.47 V</li> <li>• 0 Kg/h: 0.99 V</li> <li>• 10 Kg/h: 1.2226 ~ 1.2398 V</li> <li>• 15 Kg/h: 1.3552 ~ 1.3778 V</li> <li>• 30 Kg/h: 1.6783 ~ 1.7146 V</li> <li>• 60 Kg/h: 2.1619 ~ 2.2057 V</li> <li>• 120 Kg/h: 2.7215 ~ 2.7762 V</li> <li>• 250 Kg/h: 3.4388 ~ 3.5037 V</li> <li>• 370 Kg/h: 3.8796 ~ 3.9511 V</li> <li>• 480 Kg/h: 4.1945 ~ 4.2683 V</li> <li>• 640 Kg/h: 4.5667 ~ 4.6469 V</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>						
P0102	Low HFM Sensor Signal (Circuit Open)	<ul style="list-style-type: none"> <li>- HFM sensing values are lower than minimum sensing values.</li> <li>- Check the resistance in HFM sensor.</li> <li>- Check the ECU wiring harness (open and poor contact).</li> <li>- Actual air mass flow vs. Output voltages.           <ul style="list-style-type: none"> <li>• -20 Kg/h: 0.47 V</li> <li>• 0 Kg/h: 0.99 V</li> <li>• 10 Kg/h: 1.2226 ~ 1.2398 V</li> <li>• 15 Kg/h: 1.3552 ~ 1.3778 V</li> <li>• 30 Kg/h: 1.6783 ~ 1.7146 V</li> <li>• 60 Kg/h: 2.1619 ~ 2.2057 V</li> <li>• 120 Kg/h: 2.7215 ~ 2.7762 V</li> <li>• 250 Kg/h: 3.4388 ~ 3.5037 V</li> <li>• 370 Kg/h: 3.8796 ~ 3.9511 V</li> <li>• 480 Kg/h: 4.1945 ~ 4.2683 V</li> <li>• 640 Kg/h: 4.5667 ~ 4.6469 V</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduc- tion (max.50%)	Torque Reduc- tion (max.20%)	Delayed Engine Stop	Immedi- ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0103	High HFM Sensor Signal (Circuit Short)	<ul style="list-style-type: none"> <li>- HFM sensing values are higher than maximum sensing values.</li> <li>- Check the resistance in HFM sensor.</li> <li>- Check the ECU wiring harness (open and poor contact).</li> <li>- Actual air mass flow vs. Output voltages. <ul style="list-style-type: none"> <li>• -20 Kg/h: 0.47 V</li> <li>• 0 Kg/h: 0.99 V</li> <li>• 10 Kg/h: 1.2226 ~ 1.2398 V</li> <li>• 15 Kg/h: 1.3552 ~ 1.3778 V</li> <li>• 30 Kg/h: 1.6783 ~ 1.7146 V</li> <li>• 60 Kg/h: 2.1619 ~ 2.2057 V</li> <li>• 120 Kg/h: 2.7215 ~ 2.7762 V</li> <li>• 250 Kg/h: 3.4388 ~ 3.5037 V</li> <li>• 370 Kg/h: 3.8796 ~ 3.9511 V</li> <li>• 480 Kg/h: 4.1945 ~ 4.2683 V</li> <li>• 640 Kg/h: 4.5667 ~ 4.6469 V</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>						
P0105	Supply Voltage Fault to Booster Pressure Sensor	<ul style="list-style-type: none"> <li>- Out of range of supply voltages about boost pressure sensor at Ignition key-On and Engine Stop (Higher than specified values).</li> <li>- Check the supply voltage to sensor.</li> <li>- Actual boost pressure vs. Output voltages <ul style="list-style-type: none"> <li>• Raw Signal Range: 0.545 ~ 2.490 bar</li> <li>• 0.4 bar: 0.6120 V</li> <li>• 1.4 bar: 2.6520 V</li> <li>• 2.4 bar: 4.6920 V</li> </ul> </li> <li>- Check the sensor wiring harness (open, poor contact).</li> <li>- Visually check sensor and replace if required.</li> <li>- Replace the ECU if required.</li> <li>- Check whether existing or not about turbo boosting control malfunction (P1235) simultaneously.</li> <li>- If there is turbo boost control fault, Should be checked followings also; <ul style="list-style-type: none"> <li>• Leakage before turbo system</li> <li>• Vacuum pump malfunction</li> <li>• Waste gate' solenoid valve</li> <li>• Turbo charger system defect or malfunction itself</li> <li>• Air inlet restriction</li> <li>• Exhaust system restriction</li> </ul> </li> </ul>		0			0	

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0106	High Booster Pressure Sensor Signal	<ul style="list-style-type: none"> <li>- Out of signal range about boost pressure sensor at Ignition key-On and Engine Stop (Higher than specified values).</li> <li>- Check the supply voltage to sensor.</li> <li>- Actual boost pressure vs. Output voltages. <ul style="list-style-type: none"> <li>• Raw Signal Range: 0.545 ~ 2.490 bar</li> <li>• 0.4 bar: 0.6120 V</li> <li>• 1.4 bar: 2.6520 V</li> <li>• 2.4 bar: 4.6920 V</li> </ul> </li> <li>- Check the sensor wiring harness (open, poor contact).</li> <li>- Visually check sensor and replace if required.</li> <li>- Replace the ECU if required.</li> <li>- Check whether existing or not about turbo boosting control malfunction (P1235) simultaneously.</li> <li>- If there is turbo boost control fault, Should be checked followings also; <ul style="list-style-type: none"> <li>• Leakage before turbo system</li> <li>• Vacuum pump malfunction</li> <li>• Waste gate' solenoid valve</li> <li>• Turbo charger system defect or malfunction itself</li> <li>• Air inlet restriction</li> <li>• Exhaust system restriction</li> </ul> </li> </ul>						o
P0107	Booster Pressure Sensor Open/GND Short	<ul style="list-style-type: none"> <li>- Out of signal range about boost pressure sensor at Engine running condition (Lower than specified values).</li> <li>- Check the supply voltage to sensor.</li> <li>- Actual boost pressure vs. Output voltages <ul style="list-style-type: none"> <li>• Raw Signal Range: 0.545 ~ 2.490 bar</li> <li>• 0.4 bar: 0.6120 V</li> <li>• 1.4 bar: 2.6520 V</li> <li>• 2.4 bar: 4.6920 V</li> </ul> </li> <li>- Check the sensor wiring harness (open, poor contact).</li> <li>- Visually check sensor and replace if required.</li> <li>- Replace the ECU if required.</li> <li>- Check whether existing or not about turbo boosting control malfunction (P1235) simultaneously.</li> <li>- If there is turbo boost control fault, Should be checked followings also; <ul style="list-style-type: none"> <li>• Leakage before turbo system</li> <li>• Vacuum pump malfunction</li> <li>• Waste gate' solenoid valve</li> <li>• Turbo charger system defect or malfunction itself</li> <li>• Air inlet restriction</li> <li>• Exhaust system restriction</li> </ul> </li> </ul>		o				o

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0108	Booster Pressure Sensor Short	<ul style="list-style-type: none"> <li>- Out of signal range about boost pressure sensor at Engine running condition (Higher than specified values).</li> <li>- Check the supply voltage to sensor.</li> <li>- Actual boost pressure vs. Output voltages <ul style="list-style-type: none"> <li>• Raw Signal Range: 0.545~2.490 bar</li> <li>• 0.4 bar: 0.6120 V</li> <li>• 1.4 bar: 2.6520 V</li> <li>• 2.4 bar: 4.6920 V</li> </ul> </li> <li>- Check the sensor wiring harness (open, poor contact).</li> <li>- Visually check sensor and replace if required.</li> <li>- Replace the ECU if required.</li> <li>- Check whether existing or not about turbo boosting control malfunction (P1235) simultaneously.</li> <li>- If there is turbo boost control fault, Should be checked followings also; <ul style="list-style-type: none"> <li>• Leakage before turbo system</li> <li>• Vacuum pump malfunction</li> <li>• Waste gate' solenoid valve</li> <li>• Turbo charger system defect or malfunction itself</li> <li>• Air inlet restriction</li> <li>• Exhaust system restriction</li> </ul> </li> </ul>		o				o
P0109	Low Booster Pressure Sensor Signal	<ul style="list-style-type: none"> <li>- Out of signal range about boost pressure sensor at Ignition key-On and Engine Stop (Lower than specified values).</li> <li>- Check the supply voltage to sensor.</li> <li>- Actual boost pressure vs. Output voltages. <ul style="list-style-type: none"> <li>• Raw Signal Range: 0.545 ~ 2.490 bar</li> <li>• 0.4 bar: 0.6120 V</li> <li>• 1.4 bar: 2.6520 V</li> <li>• 2.4 bar: 4.6920 V</li> </ul> </li> <li>- Check the sensor wiring harness (open, poor contact).</li> <li>- Visually check sensor and replace if required.</li> <li>- Replace the ECU if required.</li> <li>- Check whether existing or not about turbo boosting control malfunction (P1235) simultaneously.</li> <li>- If there is turbo boost control fault, Should be checked followings also; <ul style="list-style-type: none"> <li>• Leakage before turbo system</li> <li>• Vacuum pump malfunction</li> <li>• Waste gate' solenoid valve</li> <li>• Turbo charger system defect or malfunction itself</li> <li>• Air inlet restriction</li> <li>• Exhaust system restriction</li> </ul> </li> </ul>						o

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduc- tion (max.50%)	Torque Reduc- tion (max.20%)	Delayed Engine Stop	Immedi- ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0110	Intake Air Tempera- ture Circuit Malfunc- tion - Source Power Problem	<ul style="list-style-type: none"> <li>- The intake air temperature sensing value is lower than minimum value or higher than maximum value, or the external power to HFM sensor is faulty.</li> <li>- Check the supply voltage to sensor. <ul style="list-style-type: none"> <li>• Actual air temperature vs. Voltages</li> <li>• 20°C: 2.65 Ω</li> <li>• 30°C: 2.18 Ω</li> <li>• 50°C: 1.40 Ω</li> <li>• Recovery values when intake air temperature sensor failure: 50°C</li> </ul> </li> <li>- Check the sensor wiring harness. <ul style="list-style-type: none"> <li>• Check the source power circuit for short to ground.</li> </ul> </li> <li>- Check the sensor resistance. <ul style="list-style-type: none"> <li>• Actual air temperature vs. Resistance</li> <li>• -40°C: 39.260 Ω</li> <li>• -20°C: 13.850 Ω</li> <li>• 0°C: 5.499 Ω</li> <li>• 20°C: 2.420 Ω</li> <li>• 40°C: 1.166 Ω</li> <li>• 60°C: 0.609 Ω</li> <li>• 80°C: 0.340 Ω</li> <li>• 100°C: 0.202 Ω</li> <li>• 120°C: 0.127 Ω</li> <li>• Recovery values when intake air temperature sensor failure: 50°C</li> </ul> </li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>		0				

ECU-  
GASOLINECU-  
DIESELBRAKE  
AIR-BAGCCC  
FATCP/TRUNK  
FFHRAIN  
SENSORTC  
STICSTCU  
TGS  
LEVER

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduc- tion (max.50%)	Torque Reduc- tion (max.20%)	Delayed Engine Stop	Immedi- ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0112	Intake Air Temperature Circuit Malfunction - Open	<ul style="list-style-type: none"> <li>- The intake air temperature sensing value is lower than maximum value of 150°C: Open</li> <li>- Check the supply voltage to sensor. <ul style="list-style-type: none"> <li>• Actual air temperature vs. Voltages</li> <li>• 20°C: 2.65 Ω</li> <li>• 30°C: 2.18 Ω</li> <li>• 50°C: 1.40 Ω</li> <li>• Recovery values when intake air temperature sensor failure: 50°C</li> </ul> </li> <li>- Check the sensor wiring harness. <ul style="list-style-type: none"> <li>• Check the source power circuit for short to ground.</li> </ul> </li> <li>- Check the sensor resistance. <ul style="list-style-type: none"> <li>• Actual air temperature vs. Resistance</li> <li>• -40°C: 39.260 Ω</li> <li>• -20°C: 13.850 Ω</li> <li>• 0°C: 5.499 Ω</li> <li>• 20°C: 2.420 Ω</li> <li>• 40°C: 1.166 Ω</li> <li>• 60°C: 0.609 Ω</li> <li>• 80°C: 0.340 Ω</li> <li>• 100°C: 0.202 Ω</li> <li>• 120°C: 0.127 Ω</li> <li>• Recovery values when intake air temperature sensor failure: 50°C</li> </ul> </li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>		0				

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0113	Intake Air Temperature Circuit Malfunction - Short	<ul style="list-style-type: none"> <li>- The intake air temperature sensing value is lower than maximum value of 150°C: Open</li> <li>- Check the supply voltage to sensor. <ul style="list-style-type: none"> <li>• Actual air temperature vs. Voltages</li> <li>• 20°C: 2.65 Ω</li> <li>• 30°C: 2.18 Ω</li> <li>• 50°C: 1.40 Ω</li> <li>• Recovery values when intake air temperature sensor failure: 50°C</li> </ul> </li> <li>- Check the sensor wiring harness. <ul style="list-style-type: none"> <li>• Check the source power circuit for short to ground.</li> </ul> </li> <li>- Check the sensor resistance. <ul style="list-style-type: none"> <li>• Actual air temperature vs. Resistance</li> <li>• -40°C: 39.260 Ω</li> <li>• -20°C: 13.850 Ω</li> <li>• 0°C: 5.499 Ω</li> <li>• 20°C: 2.420 Ω</li> <li>• 40°C: 1.166 Ω</li> <li>• 60°C: 0.609 Ω</li> <li>• 80°C: 0.340 Ω</li> <li>• 100°C: 0.202 Ω</li> <li>• 120°C: 0.127 Ω</li> <li>• Recovery values when intake air temperature sensor failure: 50°C</li> </ul> </li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>		O				
P0115	Supply Voltage Fault to Coolant Temperature Sensor	<ul style="list-style-type: none"> <li>- Check if the supply voltage of approx. 12 V is applied.</li> </ul>						
P0117	Coolant Temperature Sensor Malfunction - Open	<ul style="list-style-type: none"> <li>- Malfunction in recognition of coolant temperature <ul style="list-style-type: none"> <li>• Less than minimum values (Circuit Open)</li> <li>• External power supply malfunction</li> </ul> </li> <li>- If Fuel temperature is invalid, the previous coolant temperature is retained.</li> <li>- Check the supply voltage to sensor.</li> <li>- Actual air temp. vs. Resistance <ul style="list-style-type: none"> <li>• 20°C: 2449 Ω</li> <li>• 50°C: 826.3 Ω</li> <li>• 80°C: 321.4 Ω</li> <li>• 100°C: 112.9 Ω</li> </ul> </li> <li>- Check the wiring harness (open and poor contact). <ul style="list-style-type: none"> <li>• ECU pin #A01, A02</li> </ul> </li> <li>- Visually check the sensor and replace if required.</li> <li>- Replace the ECU if required.</li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduc-tion (max.50%)	Torque Reduc-tion (max.20%)	Delayed Engine Stop	Immedi-ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0118	Coolant Temperature Sensor Malfunction - Short	<ul style="list-style-type: none"> <li>- Malfunction in recognition of coolant temperature           <ul style="list-style-type: none"> <li>• More than maximum values (Circuit Short)</li> <li>• External power supply malfunction</li> </ul> </li> <li>- If Fuel temperature is invalid, the previous coolant temperature is retained.</li> <li>- Check the supply voltage to sensor.</li> <li>- Actual air temp. vs. Resistance           <ul style="list-style-type: none"> <li>• 20°C: 2449 Ω</li> <li>• 50°C: 826.3 Ω</li> <li>• 80°C: 321.4 Ω</li> <li>• 100°C: 112.9 Ω</li> </ul> </li> <li>- Check the wiring harness (short and poor contact).           <ul style="list-style-type: none"> <li>• ECU pin #A01, A02</li> </ul> </li> <li>- Visually check the sensor and replace if required.</li> <li>- Replace the ECU if required.</li> </ul>						
P0120	Accelerator Pedal Sensor #1 Malfunc-tion - Supply Voltage Fault	<ul style="list-style-type: none"> <li>- The supply voltage is faulty.</li> <li>- Check the supply voltage to sensor.</li> <li>- Check the wiring harness.           <ul style="list-style-type: none"> <li>• Check the circuit for open and short.</li> </ul> </li> <li>- Check the accelerator pedal.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>	0					0
P0122	Accelerator Pedal Sensor #1 Malfunc-tion - Open	<ul style="list-style-type: none"> <li>- Out of range about potentiometer 1 of pedal sensor: lower than specified values</li> <li>- Check the supply voltage to sensor.</li> <li>- Check the wiring harness.           <ul style="list-style-type: none"> <li>• Check the circuit for open and short.</li> </ul> </li> <li>- Check the accelerator pedal.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>	0					0
P0123	Accelerator Pedal Sensor #1 Malfunc-tion - Short	<ul style="list-style-type: none"> <li>- Out of range about potentiometer 1 of pedal sensor: higher than specified values</li> <li>- Check the supply voltage to sensor.</li> <li>- Check the wiring harness.           <ul style="list-style-type: none"> <li>• Check the circuit for open and short.</li> </ul> </li> <li>- Check the accelerator pedal.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>	0					0

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0147	Impossible to Learn Idle MDP	<ul style="list-style-type: none"> <li>- Causes (Idle range MDP learning) <ul style="list-style-type: none"> <li>• The MDP is not learned again until driving over 50,000 km after the MDP is learned.</li> </ul> </li> <li>- Conditions for MDP learning (Idle) <ul style="list-style-type: none"> <li>• Leaning twice for each cylinder (attempt every 5 sec.)</li> <li>• Initial MDP learning: coolant temperature &gt; 60°C</li> <li>• Fuel temperature: 0 ~ 80°C</li> <li>• Vehicle speed: Idle.</li> <li>• The tachometer's needle vibrates while learning idle MDP.</li> <li>• Replace ECU after learning.</li> </ul> </li> </ul>						
P0148	Impossible to Learn Drive MDP	<ul style="list-style-type: none"> <li>- Causes <ul style="list-style-type: none"> <li>• It occurs twice for each cylinder if MDP is not learned again until driving over 50,000 km after the MDP is learned.</li> </ul> </li> <li>- Actions <ul style="list-style-type: none"> <li>• Check knock sensor and wiring.</li> <li>• Check injector specification.</li> <li>• Check C3I/C2I.</li> </ul> </li> </ul>						
P0171	Insufficient MDP of Injector #1	- MDP learning value is decreased due to aged injector #1.						
P0172	Insufficient MDP of Injector #2	- MDP learning value is decreased due to aged injector #2.						
P0173	Insufficient MDP of Injector #3	- MDP learning value is decreased due to aged injector #3.						
P0174	Insufficient MDP of Injector #4	- MDP learning value is decreased due to aged injector #4.						
P0175	Insufficient MDP of Injector #5	- MDP learning value is decreased due to aged injector #5.						
P0180	Fuel Temperature Sensor - Malfunction	<ul style="list-style-type: none"> <li>- The power source circuit is faulty for fuel temperature sensor. (Fuel temperature sensor is mounted in high pressure pump)</li> <li>- Actual fuel temp. vs. Resistance <ul style="list-style-type: none"> <li>• -40°C: 75.780 Ω -20°C: 21.873 Ω</li> <li>• -10°C: 12.462 Ω 0°C: 7.355 Ω</li> <li>• 10°C: 4.481 Ω 20°C: 2.812 Ω</li> <li>• 25°C: 2.252 Ω 30°C: 1.814 Ω</li> <li>• 40°C: 1.199 Ω 50°C: 0.811 Ω</li> <li>• 70°C: 0.394 Ω 90°C: 0.206 Ω</li> <li>• 120°C: 0.087 Ω</li> </ul> </li> <li>- Recovery values when fuel temperature sensor failure: 95°C</li> <li>- Check the supply voltage to sensor.</li> <li>- Check the wiring harness for open, short and poor contact. <ul style="list-style-type: none"> <li>• ECU pin #A09, A10</li> </ul> </li> <li>- Check the ECU wiring and replace the ECU if required.</li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0182	Fuel Temperature Sensor - Short to Ground	<ul style="list-style-type: none"> <li>- The sensing values are higher than specified values for fuel temperature sensor. (More than maximum sensing values 140°C - Circuit Short)</li> <li>- Actual fuel temp. vs. Resistance <ul style="list-style-type: none"> <li>• -40°C: 75.780 Ω -20°C: 21.873 Ω</li> <li>• -10°C: 12.462 Ω 0°C: 7.355 Ω</li> <li>• 10°C: 4.481 Ω 20°C: 2.812 Ω</li> <li>• 25°C: 2.252 Ω 30°C: 1.814 Ω</li> <li>• 40°C: 1.199 Ω 50°C: 0.811 Ω</li> <li>• 70°C: 0.394 Ω 90°C: 0.206 Ω</li> <li>• 120°C: 0.087 Ω</li> </ul> </li> <li>- Recovery values when fuel temperature sensor failure: 95°C</li> <li>- Check the supply voltage to sensor.</li> <li>- Check the wiring harness for open, short and poor contact. <ul style="list-style-type: none"> <li>• ECU pin #A09, A10</li> </ul> </li> <li>- Check the ECU wiring and replace the ECU if required.</li> </ul>						
P0183	Fuel Temperature Sensor - Short to B+	<ul style="list-style-type: none"> <li>- The sensing values are lower than specified values for fuel temperature sensor. (Less than maximum sensing values - 40°C - Circuit Open)</li> <li>- Actual fuel temp. vs. Resistance <ul style="list-style-type: none"> <li>• -40°C: 75.780 Ω -20°C: 21.873 Ω</li> <li>• -10°C: 12.462 Ω 0°C: 7.355 Ω</li> <li>• 10°C: 4.481 Ω 20°C: 2.812 Ω</li> <li>• 25°C: 2.252 Ω 30°C: 1.814 Ω</li> <li>• 40°C: 1.199 Ω 50°C: 0.811 Ω</li> <li>• 70°C: 0.394 Ω 90°C: 0.206 Ω</li> <li>• 120°C: 0.087 Ω</li> </ul> </li> <li>- Recovery values when fuel temperature sensor failure: 95°C</li> <li>- Check the supply voltage to sensor.</li> <li>- Check the wiring harness for open, short and poor contact.</li> <li>- Check the ECU wiring and replace the ECU if required.</li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0190	Supply Voltage Fault to Fuel Rail Pressure Sensor	<ul style="list-style-type: none"> <li>The supply voltage to fuel rail pressure sensor is faulty.</li> <li>Check the supply voltage to sensor. <ul style="list-style-type: none"> <li>Output voltage at 1600 bar: <math>4.055 \pm 0.125</math> V</li> <li>Output voltage at atmospheric pressure: <math>0.5 \pm 0.04</math> V</li> </ul> </li> <li>Check the sensor and ECU wiring harness. <ul style="list-style-type: none"> <li>Check the fuel rails and high pressure pipes for leaks.</li> </ul> </li> <li>Check the fuel rail pressure sensor.</li> <li>Replace the ECU if required.</li> </ul>	o					o
P0191	Fuel Rail Pressure Sensor Signal Fault	<ul style="list-style-type: none"> <li>The rail pressure drop is too high.</li> <li>Check the supply voltage to sensor. <ul style="list-style-type: none"> <li>Output voltage at 1600 bar: <math>4.055 \pm 0.125</math> V</li> <li>Output voltage at atmospheric pressure: <math>0.5 \pm 0.04</math> V</li> </ul> </li> <li>Check the sensor and ECU wiring harness. <ul style="list-style-type: none"> <li>Check the fuel rails and high pressure pipes for leaks.</li> </ul> </li> <li>Check the fuel rail pressure sensor.</li> <li>Replace the ECU if required.</li> </ul>	o					o
P0192	Fuel Rail Pressure Sensor Malfunction - Open	<ul style="list-style-type: none"> <li>The fuel rail pressure sensing values are lower than specified values. <ul style="list-style-type: none"> <li>Minimum sensing values: - 112 bar (Open)</li> </ul> </li> <li>Check the supply voltage to sensor. <ul style="list-style-type: none"> <li>Output voltage at 1600 bar: <math>4.055 \pm 0.125</math> V</li> <li>Output voltage at atmospheric pressure: <math>0.5 \pm 0.04</math> V</li> </ul> </li> <li>Check the sensor and ECU wiring harness. <ul style="list-style-type: none"> <li>Check the fuel rails and high pressure pipes for leaks.</li> </ul> </li> <li>Check the fuel rail pressure sensor.</li> <li>Replace the ECU if required.</li> </ul>	o					o

ECU-GASOLIN
ECU-DIESEL
BRAKE
AIR-BAG
P/TRUNK
FFH
FATC
TC
STICS
RAIN SENSOR
TCU
TGS LEVER

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0193	Fuel Rail Pressure Sensor Malfunction - Short	<ul style="list-style-type: none"> <li>- The fuel rail pressure sensing values are higher than specified values.           <ul style="list-style-type: none"> <li>• Maximum sensing values: 1,600 bar (Short)</li> </ul> </li> <li>- Check the supply voltage to sensor.           <ul style="list-style-type: none"> <li>• Output voltage at 1600 bar: 4.055± 0.125V</li> <li>• Output voltage at atmospheric pressure: 0.5±0.04V</li> </ul> </li> <li>- Check the sensor and ECU wiring harness.           <ul style="list-style-type: none"> <li>• Check the fuel rails and high pressure pipes for leaks.</li> </ul> </li> <li>- Check the fuel rail pressure sensor.</li> <li>- Replace the ECU if required.</li> </ul>	o					o
P0201	Injector #1 Circuit Open	<ul style="list-style-type: none"> <li>- Injector #1 circuit malfunction: Open.           <ul style="list-style-type: none"> <li>• If the injector pin is defective, perform C2l/C3l coding and check again.</li> <li>• If the injector pin is normal, check the ECU wiring harness .</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>						o
P0202	Injector #2 Circuit Open	<ul style="list-style-type: none"> <li>- Injector #2 circuit malfunction: Open.           <ul style="list-style-type: none"> <li>• If the injector pin is defective, perform C2l/C3l coding and check again.</li> <li>• If the injector pin is normal, check the ECU wiring harness.</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>						o
P0203	Injector #3 Circuit Open	<ul style="list-style-type: none"> <li>- Injector #3 circuit malfunction: Open.           <ul style="list-style-type: none"> <li>• If the injector pin is defective, perform C2l/C3l coding and check again.</li> <li>• If the injector pin is normal, check the ECU wiring harness.</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>						o
P0204	Injector #4 Circuit Open	<ul style="list-style-type: none"> <li>- Injector #4 circuit malfunction: Open.           <ul style="list-style-type: none"> <li>• If the injector pin is defective, perform C2l/C3l coding and check again.</li> <li>• If the injector pin is normal, check the ECU wiring harness.</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>						o
P0205	Injector #5 Circuit Open	<ul style="list-style-type: none"> <li>- Injector #5 circuit malfunction: Open.           <ul style="list-style-type: none"> <li>• If the injector pin is defective, perform C2l/C3l coding and check again.</li> <li>• If the injector pin is normal, check the ECU wiring harness.</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>						o

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0215	Main Relay Fault - Stuck	<ul style="list-style-type: none"> <li>- The main relay is stuck ; Shut down.</li> <li>- Resistance of main relay: <math>92 \Omega \pm 9 \Omega</math> (at <math>20^\circ\text{C}</math>)</li> <li>- Check the main relay wiring harness.</li> <li>- Check the ECU wiring harness.</li> <li>- If the forced operation is not available, replace the ECU.</li> <li>- Check the fuse for main relay</li> </ul>						
P0219	Too Small Clearance of Crank Angle Sensor	<ul style="list-style-type: none"> <li>- Crank angle signal faults or clearance too close.</li> <li>- Check the sensor wiring harness (open, short, poor contact).</li> <li>- Check the resistance of crank angle sensor: <math>1090 \Omega \pm 15 \%</math>.</li> <li>- Measure the air gap: <math>0.3 \sim 1.3 \text{ mm}</math> <ul style="list-style-type: none"> <li>• <math>1.3 \text{ mm}</math> of air gap: outputs <math>1.0 \text{ V}</math> at <math>40 \text{ rpm}</math></li> <li>• <math>0.3 \text{ mm}</math> of air gap: outputs <math>150 \text{ V}</math> at <math>7000 \text{ rpm}</math></li> </ul> </li> <li>- Check the teeth condition. <ul style="list-style-type: none"> <li>• Drive plate (A/T), DMF (M/T)</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>					o	
P0220	Accelerator Pedal Sensor #2 Malfunction - Supply Voltage Fault	<ul style="list-style-type: none"> <li>- The supply voltage is faulty.</li> <li>- Check the supply voltage to sensor.</li> <li>- Check the wiring harness. <ul style="list-style-type: none"> <li>• Check the circuit for open and short.</li> </ul> </li> <li>- Check the accelerator pedal.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>	o					o
P0222	Accelerator Pedal Sensor #2 Malfunction - Open	<ul style="list-style-type: none"> <li>- Out of range about potentiometer 2 of pedal sensor: lower than specified values</li> <li>- Check the supply voltage to sensor.</li> <li>- Check the wiring harness. <ul style="list-style-type: none"> <li>• Check the circuit for open and short.</li> </ul> </li> <li>- Check the accelerator pedal.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>	o					o
P0223	Accelerator Pedal Sensor #2 Malfunction - Short	<ul style="list-style-type: none"> <li>- Out of range about potentiometer 2 of pedal sensor: higher than specified values</li> <li>- Check the supply voltage to sensor.</li> <li>- Check the wiring harness. <ul style="list-style-type: none"> <li>• Check the circuit for open and short.</li> </ul> </li> <li>- Check the accelerator pedal.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>	o					o

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0243	VGT Turbocharger Actuator Circuit Short	<ul style="list-style-type: none"> <li>- Causes <ul style="list-style-type: none"> <li>• There is electric problem in the vacuum modulator drive module of turbocharger.</li> </ul> </li> <li>- Check pin for the followings (Vacuum Modulator): <ul style="list-style-type: none"> <li>• Power (Main Relay)</li> <li>• GND</li> </ul> </li> <li>- Actions <ul style="list-style-type: none"> <li>• Check the unit's resistance (15.4 +/- 0.7 Ω) and wiring.</li> <li>• Check the input voltage (12V).</li> <li>• Visually check the unit and replace if necessary.</li> </ul> </li> </ul>						
P0245	Turbo Charger Actuator Circuit Fault - Short	<ul style="list-style-type: none"> <li>- The waste gate driver circuit is short to ground or open</li> <li>- Check the actuator wiring harness.</li> <li>- Check the solenoid valve.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>	o					o
P0246	Turbo Charger Actuator Circuit Fault - Short to B+	<ul style="list-style-type: none"> <li>- The turbo charger actuator power source circuit is short.</li> <li>- Check the actuator wiring harness.</li> <li>- Check the solenoid valve.</li> <li>- Check the ECU wiring harness for short and poor contact.</li> <li>- Replace the ECU if required.</li> </ul>	o					o
P0251	IMV Driver Circuit Malfunction - Short	<ul style="list-style-type: none"> <li>- IMV driver circuit malfunction: Short</li> <li>- Check the IMV wiring harness.</li> <li>- Check the ECU wiring harness.</li> <li>- Check the IMV resistance. <ul style="list-style-type: none"> <li>• When out of specified value: replace high pressure pump and IMV</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>			o		o	o
P0253	IMV Driver Circuit Malfunction - Short to Ground	<ul style="list-style-type: none"> <li>- IMV driver circuit malfunction: Short to ground</li> <li>- Check the IMV wiring harness.</li> <li>- Check the ECU wiring harness.</li> <li>- Check the IMV resistance. <ul style="list-style-type: none"> <li>• When out of specified value: replace high pressure pump and IMV</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>			o		o	o
P0255	IMV Driver Circuit Malfunction - Open	<ul style="list-style-type: none"> <li>- IMV driver circuit malfunction: Open</li> <li>- Check the IMV wiring harness.</li> <li>- Check the ECU wiring harness.</li> <li>- Check the IMV resistance. <ul style="list-style-type: none"> <li>• When out of specified value: replace high pressure pump and IMV</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>			o		o	o

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0263	Injector #1 Balancing Fault	<ul style="list-style-type: none"> <li>- Injector #1 cylinder balancing faults (Injector stuck closed).</li> <li>- Check the injector circuit for open.</li> <li>- Check the glow plug.</li> <li>- Check the inlet tube for clogging.</li> <li>- Check the EGR.</li> <li>- Replace the ECU if required (perform C2I/C3I coding after replacement).</li> </ul>						
P0266	Injector #2 Balancing Fault	<ul style="list-style-type: none"> <li>- Injector #2 cylinder balancing faults (Injector stuck closed).</li> <li>- Check the injector circuit for open.</li> <li>- Check the glow plug.</li> <li>- Check the inlet tube for clogging.</li> <li>- Check the EGR.</li> <li>- Replace the ECU if required (perform C2I/C3I coding after replacement).</li> </ul>						
P0269	Injector #3 Balancing Fault	<ul style="list-style-type: none"> <li>- Injector #3 cylinder balancing faults (Injector stuck closed).</li> <li>- Check the injector circuit for open.</li> <li>- Check the glow plug.</li> <li>- Check the inlet tube for clogging.</li> <li>- Check the EGR.</li> <li>- Replace the ECU if required (perform C2I/C3I coding after replacement).</li> </ul>						
P0272	Injector #4 Balancing Fault	<ul style="list-style-type: none"> <li>- Injector #4 cylinder balancing faults (Injector stuck closed).</li> <li>- Check the injector circuit for open.</li> <li>- Check the glow plug.</li> <li>- Check the inlet tube for clogging.</li> <li>- Check the EGR.</li> <li>- Replace the ECU if required (perform C2I/C3I coding after replacement).</li> </ul>						
P0275	Injector #5 Balancing Fault	<ul style="list-style-type: none"> <li>- Injector #5 cylinder balancing faults (Injector stuck closed).</li> <li>- Check the injector circuit for open.</li> <li>- Check the glow plug.</li> <li>- Check the inlet tube for clogging.</li> <li>- Check the EGR.</li> <li>- Replace the ECU if required (perform C2I/C3I coding after replacement).</li> </ul>						
P0325	Accelerometer #1 (Knock Sensor) Malfunction	<ul style="list-style-type: none"> <li>- The signal / noise ratio is too low about accelerometer # 1.</li> <li>- Check the accelerometer wiring harness and tightening torque. <ul style="list-style-type: none"> <li>• Tightening torque: <math>20 \pm 5</math> Nm</li> </ul> </li> <li>- Check the ECU wiring harness for open and short.</li> <li>- If the trouble still exists even after replacing the accelerometer, replace the ECU.</li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0325	Accelerometer #1 (Knock Sensor) Malfunction	<ul style="list-style-type: none"> <li>The signal / noise ratio is too low about accelerometer # 1.</li> <li>Check the accelerometer wiring harness and tightening torque. <ul style="list-style-type: none"> <li>Tightening torque: <math>20 \pm 5</math> Nm</li> </ul> </li> <li>Check the ECU wiring harness for open and short.</li> <li>If the trouble still exists even after replacing the accelerometer, replace the ECU.</li> </ul>						
P0335	No Crank Signals	<ul style="list-style-type: none"> <li>Refer to P0372.</li> </ul>					<b>0</b>	
P0336	Too Large Clearance of Crank Angle Sensor	<ul style="list-style-type: none"> <li>Air gap of crank angle sensor is abnormal.</li> <li>Check the sensor wiring harness (open, short, poor contact).</li> <li>Check the resistance of crank angle sensor: <math>1090 \Omega \pm 15\%</math>.</li> <li>Measure the air gap: <math>0.3 \sim 1.3</math> mm <ul style="list-style-type: none"> <li><math>1.3</math> mm of air gap: outputs <math>1.0</math> V at <math>40</math> rpm</li> <li><math>0.3</math> mm of air gap: outputs <math>150</math> V at <math>7000</math> rpm</li> </ul> </li> <li>Check the teeth condition. <ul style="list-style-type: none"> <li>Drive plate (A/T), DMF (M/T)</li> </ul> </li> <li>Replace the ECU if required.</li> </ul>					<b>0</b>	
P0341	Cam Position Sensor Malfunction (Poor Synchronization)	<ul style="list-style-type: none"> <li>Not synchronized with Crank angle signal.</li> <li>Check the source voltage of cam position sensor (specified value: <math>4.5 \sim 12</math> V).</li> <li>Check the sensor wiring harness (open, short, poor contact).</li> <li>Check the cam position sensor.</li> <li>Measure the air gap: <math>0.2 \sim 1.8</math> mm</li> <li>Replace the ECU if required.</li> </ul>					<b>0</b>	
P0344	Cam Position Sensor Malfunction	<ul style="list-style-type: none"> <li>No cam recognition signal (missing events).</li> <li>Check the source voltage of cam position sensor (specified value: <math>4.5 \sim 12</math> V).</li> <li>Check the sensor wiring harness (open, short, poor contact).</li> <li>Check the cam position sensor.</li> <li>Measure the air gap: <math>0.2 \sim 1.8</math> mm</li> <li>Replace the ECU if required.</li> </ul>					<b>0</b>	

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0372	Crank Angle Sensor Malfunction	<ul style="list-style-type: none"> <li>- Even though cam position recognition is normal, no crank angle signal recognition (missing tooth).</li> <li>- Check the sensor wiring harness (open, short, poor contact).</li> <li>- Check the resistance of crank angle sensor: <math>1090 \Omega \pm 15\%</math>.</li> <li>- Measure the air gap: <math>0.3 \sim 1.3</math> mm <ul style="list-style-type: none"> <li>• <math>1.3</math> mm of air gap: outputs <math>1.0</math> V at <math>40</math> rpm</li> <li>• <math>0.3</math> mm of air gap: outputs <math>150</math> V at <math>7000</math> rpm</li> </ul> </li> <li>- Check the teeth condition. <ul style="list-style-type: none"> <li>• Drive plate (A/T), DMF (M/T)</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>						o
P0400	EGR Control Valve Fault	<ul style="list-style-type: none"> <li>- When the EGR emission is more than specified value. <ul style="list-style-type: none"> <li>• The EGR controller circuit is open or short to ground.</li> <li>• The EGR controller is short to battery.</li> </ul> </li> <li>- Check the EGR actuator wiring harness.</li> <li>- Check the supply voltage to EGR solenoid valve.</li> <li>- Check if the EGR valve is stuck.</li> <li>- Check the resistance of EGR valve: <math>15.4 \Omega</math>.</li> <li>- Check the ECU wiring harness.</li> </ul>						
P0401	EGR Control Valve Fault (Low)	<ul style="list-style-type: none"> <li>- When the EGR emission is more than specified value. <ul style="list-style-type: none"> <li>• The EGR controller circuit is open or short to ground.</li> <li>• The EGR controller is short to battery.</li> </ul> </li> <li>- Check the EGR actuator wiring harness.</li> <li>- Check the supply voltage to EGR solenoid valve.</li> <li>- Check if the EGR valve is stuck.</li> <li>- Check the resistance of EGR valve: <math>15.4 \Omega</math>.</li> <li>- Check the ECU wiring harness.</li> </ul>						
P0402	EGR Valve Stuck in Open Position	<ul style="list-style-type: none"> <li>- Causes <ul style="list-style-type: none"> <li>• The E-EGR valve is stuck with it open.</li> </ul> </li> <li>- Check pin (refer to the page 1407)</li> <li>- Actions <ul style="list-style-type: none"> <li>• Check E-EGR valve and sensor wiring.</li> <li>• Visually check the unit and replace if necessary.</li> <li>• Replace the ECU if required.</li> <li>• Refer to DTCs (P0407 and P0408).</li> </ul> </li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduc-tion (max.50%)	Torque Reduc-tion (max.20%)	Delayed Engine Stop	Immedi-ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0405	High EGR Open Position Deviation	<ul style="list-style-type: none"> <li>- Causes <ul style="list-style-type: none"> <li>• The difference between E-EGR position demand (MAP) value and E-EGR position feedback signal value is over 15% (the sensor output indicates E-EGR is open over 15% in the close status).</li> </ul> </li> <li>- Actions <ul style="list-style-type: none"> <li>• Measure the resistance of E-EGR valve sensor.</li> <li>• Check the sensor and actuator wiring harness.</li> <li>• Check the unit.</li> </ul> </li> </ul>						0
P0406	High EGR Close Position Deviation	<ul style="list-style-type: none"> <li>- Causes <ul style="list-style-type: none"> <li>• The difference between E-EGR position demand (MAP) value and E-EGR position feedback signal value is over 15% (the sensor output indicates E-EGR is closed over 15% in the open status).</li> </ul> </li> <li>- Actions <ul style="list-style-type: none"> <li>• Measure the resistance of E-EGR valve sensor.</li> <li>• Check the sensor and actuator wiring harness.</li> <li>• Check the unit.</li> </ul> </li> </ul>		0				
P0407	Low EGR Position Signal	<ul style="list-style-type: none"> <li>- Diagnosis of E-EGR signal for the followings: <ul style="list-style-type: none"> <li>• Sensor signal is high or low.</li> <li>• Total resistance value: <math>4\Omega \pm 40\%</math></li> <li>• Sensor output range: <math>1.2 \sim 4.0 \text{ V}</math></li> <li>• Total sensor resistance: <math>4 \text{ k}\Omega \pm 40\%</math></li> <li>• Total motor resistance: <math>8.0\Omega \pm 0.5\Omega</math></li> </ul> </li> <li>- Check pin for the followings: <ul style="list-style-type: none"> <li>• Check sensor reference voltage (5V) - ECU Pin #A33</li> <li>• Sensor signal - ECU Pin #A82</li> <li>• Sensor GND - ECU Pin #A09</li> </ul> </li> <li>- Actions <ul style="list-style-type: none"> <li>• Measure the resistance of E-EGR valve sensor.</li> <li>• Check the sensor and actuator wiring harness.</li> <li>• Check the unit.</li> </ul> </li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp																																							
P0408	High EGR Position Signal	<ul style="list-style-type: none"> <li>- Diagnosis of E-EGR signal for the followings:           <ul style="list-style-type: none"> <li>• Sensor signal is high or low.</li> <li>• Total resistance value: <math>4\Omega \pm 40\%</math></li> <li>• Sensor output range: <math>1.2 \sim 4.0 \text{ V}</math></li> <li>• Total sensor resistance: <math>4 \text{ k}\Omega \pm 40\%</math></li> <li>• Total motor resistance: <math>8.0\Omega \pm 0.5\Omega</math></li> </ul> </li> <li>- Check pin for the followings:           <ul style="list-style-type: none"> <li>• Check sensor reference voltage (5V)</li> <li>• Sensor signal - ECU pin #A82</li> <li>• Sensor GND - ECU pin #A09</li> </ul> </li> <li>- Actions           <ul style="list-style-type: none"> <li>• Measure the resistance of E-EGR valve sensor.</li> <li>• Check the sensor and actuator wiring harness.</li> <li>• Check the unit.</li> </ul> </li> </ul>																																													
P0430	Front and Rear Exhaust Gas Temperature Sensors - Excessive Temperature Value Difference	<ul style="list-style-type: none"> <li>- The value difference between the front exhaust gas temperature sensor on the exhaust manifold and the rear exhaust gas temperature sensor on the CDPF is out of the specified range.</li> <li>- Measure the resistance of the exhaust gas temperature sensors by temperature and the supplied voltage.</li> <li>- Check the ECU terminal No. A06 and A30 for connecting the front exhaust gas temperature sensor as well as the sensor terminal No. 1 and 2.</li> <li>- Check the ECU terminal No. A23 and A42 for connecting the rear exhaust gas temperature sensor as well as the sensor terminal No. 1 and 2.</li> </ul> <table border="1" data-bbox="568 1455 890 1971"> <thead> <tr> <th>CDPF temperature (°C)</th> <th>Resistance (Ω)</th> </tr> </thead> <tbody> <tr><td>-40</td><td>169.18</td></tr> <tr><td>-20</td><td>184.64</td></tr> <tr><td>0</td><td>200.0</td></tr> <tr><td>25</td><td>219.07</td></tr> <tr><td>50</td><td>237.99</td></tr> <tr><td>100</td><td>275.4</td></tr> <tr><td>150</td><td>312.2</td></tr> <tr><td>200</td><td>348.5</td></tr> <tr><td>250</td><td>384.1</td></tr> <tr><td>300</td><td>419.2</td></tr> <tr><td>350</td><td>453.7</td></tr> <tr><td>400</td><td>487.6</td></tr> <tr><td>450</td><td>520.9</td></tr> <tr><td>500</td><td>553.6</td></tr> <tr><td>600</td><td>617.3</td></tr> <tr><td>700</td><td>678.7</td></tr> <tr><td>800</td><td>737.7</td></tr> <tr><td>830</td><td>754.9</td></tr> <tr><td>850</td><td>766.3</td></tr> </tbody> </table>	CDPF temperature (°C)	Resistance (Ω)	-40	169.18	-20	184.64	0	200.0	25	219.07	50	237.99	100	275.4	150	312.2	200	348.5	250	384.1	300	419.2	350	453.7	400	487.6	450	520.9	500	553.6	600	617.3	700	678.7	800	737.7	830	754.9	850	766.3					o
CDPF temperature (°C)	Resistance (Ω)																																														
-40	169.18																																														
-20	184.64																																														
0	200.0																																														
25	219.07																																														
50	237.99																																														
100	275.4																																														
150	312.2																																														
200	348.5																																														
250	384.1																																														
300	419.2																																														
350	453.7																																														
400	487.6																																														
450	520.9																																														
500	553.6																																														
600	617.3																																														
700	678.7																																														
800	737.7																																														
830	754.9																																														
850	766.3																																														

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp																																							
P0431	DOC malfunction	<ul style="list-style-type: none"> <li>The measured DOC temperature is below the limit for recycling (below 0.5 times).</li> <li>Cause: Old/worn DOC</li> <li>The recycling mode cannot be activated.</li> <li>Check and clear the DTC using SCAN-100.</li> <li>Replace the CDPF.</li> </ul>						o																																							
P0432	CDPF - Excessive Soot Accumulated	<ul style="list-style-type: none"> <li>The pressure is over 23 Kpa for over 960 seconds due to the resistance by soot.</li> <li>If P0432 is generated without error in pressure sensor, the torque is reduced.</li> <li>Remove CDPF and clean it by blowing it from the opposite side of discharged side. Then, install it again and check it for soot.</li> </ul>						o																																							
P0436	Rear exhaust gas temperature sensor - faulty signal	<ul style="list-style-type: none"> <li>The signal value from the rear exhaust gas temperature sensor is over the specified range.</li> <li>See P0437 and P0438 for more information and inspection.</li> </ul>						o																																							
P0437	Rear exhaust gas temperature sensor - low signal	<ul style="list-style-type: none"> <li>The signal value from the rear exhaust gas temperature sensor is below the specified range.</li> <li>Check the ECU terminal No. A23 and A42 for connecting the rear exhaust gas temperature sensor as well as the sensor terminal No. 1 and 2.</li> </ul> <table border="1"> <thead> <tr> <th>CDPF temperature (°C)</th><th>Resistance (Ω)</th></tr> </thead> <tbody> <tr><td>-40</td><td>169.18</td></tr> <tr><td>-20</td><td>184.64</td></tr> <tr><td>0</td><td>200.0</td></tr> <tr><td>25</td><td>219.07</td></tr> <tr><td>50</td><td>237.99</td></tr> <tr><td>100</td><td>275.4</td></tr> <tr><td>150</td><td>312.2</td></tr> <tr><td>200</td><td>348.5</td></tr> <tr><td>250</td><td>384.1</td></tr> <tr><td>300</td><td>419.2</td></tr> <tr><td>350</td><td>453.7</td></tr> <tr><td>400</td><td>487.6</td></tr> <tr><td>450</td><td>520.9</td></tr> <tr><td>500</td><td>553.6</td></tr> <tr><td>600</td><td>617.3</td></tr> <tr><td>700</td><td>678.7</td></tr> <tr><td>800</td><td>737.7</td></tr> <tr><td>830</td><td>754.9</td></tr> <tr><td>850</td><td>766.3</td></tr> </tbody> </table>	CDPF temperature (°C)	Resistance (Ω)	-40	169.18	-20	184.64	0	200.0	25	219.07	50	237.99	100	275.4	150	312.2	200	348.5	250	384.1	300	419.2	350	453.7	400	487.6	450	520.9	500	553.6	600	617.3	700	678.7	800	737.7	830	754.9	850	766.3					o
CDPF temperature (°C)	Resistance (Ω)																																														
-40	169.18																																														
-20	184.64																																														
0	200.0																																														
25	219.07																																														
50	237.99																																														
100	275.4																																														
150	312.2																																														
200	348.5																																														
250	384.1																																														
300	419.2																																														
350	453.7																																														
400	487.6																																														
450	520.9																																														
500	553.6																																														
600	617.3																																														
700	678.7																																														
800	737.7																																														
830	754.9																																														
850	766.3																																														

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp																																								
P0438	Rear exhaust gas temperature sensor - high signal	<ul style="list-style-type: none"> <li>The signal value from the rear exhaust gas temperature sensor is over the specified range.</li> <li>Check the ECU terminal No. A23 and A42 for connecting the rear exhaust gas temperature sensor as well as the sensor terminal No. 1 and 2.</li> </ul> <table border="1"> <thead> <tr> <th>CDPF temperature (°C)</th><th>Resistance (Ω)</th></tr> </thead> <tbody> <tr><td>-40</td><td>169.18</td></tr> <tr><td>-20</td><td>184.64</td></tr> <tr><td>0</td><td>200.0</td></tr> <tr><td>25</td><td>219.07</td></tr> <tr><td>50</td><td>237.99</td></tr> <tr><td>100</td><td>275.4</td></tr> <tr><td>150</td><td>312.2</td></tr> <tr><td>200</td><td>348.5</td></tr> <tr><td>250</td><td>384.1</td></tr> <tr><td>300</td><td>419.2</td></tr> <tr><td>350</td><td>453.7</td></tr> <tr><td>400</td><td>487.6</td></tr> <tr><td>450</td><td>520.9</td></tr> <tr><td>500</td><td>553.6</td></tr> <tr><td>600</td><td>617.3</td></tr> <tr><td>700</td><td>678.7</td></tr> <tr><td>800</td><td>737.7</td></tr> <tr><td>830</td><td>754.9</td></tr> <tr><td>850</td><td>766.3</td></tr> </tbody> </table>	CDPF temperature (°C)	Resistance (Ω)	-40	169.18	-20	184.64	0	200.0	25	219.07	50	237.99	100	275.4	150	312.2	200	348.5	250	384.1	300	419.2	350	453.7	400	487.6	450	520.9	500	553.6	600	617.3	700	678.7	800	737.7	830	754.9	850	766.3						o
CDPF temperature (°C)	Resistance (Ω)																																															
-40	169.18																																															
-20	184.64																																															
0	200.0																																															
25	219.07																																															
50	237.99																																															
100	275.4																																															
150	312.2																																															
200	348.5																																															
250	384.1																																															
300	419.2																																															
350	453.7																																															
400	487.6																																															
450	520.9																																															
500	553.6																																															
600	617.3																																															
700	678.7																																															
800	737.7																																															
830	754.9																																															
850	766.3																																															
P043A	Rear exhaust gas temperature sensor - faulty voltage supply	<ul style="list-style-type: none"> <li>The supplied voltage of the rear exhaust gas temperature sensor is out of the specified range.</li> <li>Check the ECU terminal No. A42 for connecting the rear exhaust gas temperature sensor as well as the sensor terminal No. 1.</li> </ul>						o																																								
P0470	Differential Pressure Sensor - Max./Min. Output	<ul style="list-style-type: none"> <li>Specification for output value of pressure sensor : 0.5 ~4.5V</li> <li>The output value of sensor is over 4.5 V or below 0.5 V.</li> <li>Check the pressure sensor wiring for open or short circuit.</li> </ul>						o																																								
P0471	Differential Pressure Sensor - Abnormal Differential Pressure	<ul style="list-style-type: none"> <li>The actual (measured) pressure difference (actual pressure) is different from the calculated pressure difference (pressure difference between front and rear side of CDPF). (Possible cause : malfunctioning pressure sensor, leakage in pressure tube, parts removed)</li> </ul>						o																																								
P0480	PWM Electric Fan Malfunction (Open circuit) (Only for D27DTP (POWER UP) model)	<ul style="list-style-type: none"> <li>The communication line between PWM electric fan and ECU is open.</li> <li>The PWM electric fan's own malfunction cannot be identified.</li> </ul>																																														

Modification basis	
Application basis	
Affected VIN	

ECU-GASOLINE  
 ECU-DIESEL  
 BRAKE  
 AIR-BAG  
 CCCS  
 P/TRUNK  
 FFH  
 FATC  
 STICS  
 TC  
 TCU  
 TGS LEVER

DTC	Trouble	Help	Torque Reduc-tion (max.50%)	Torque Reduc-tion (max.20%)	Delayed Engine Stop	Immedi-ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0481	PWM Electric Fan Malfunction(Short to B+) (Only for D27DTP (POWER UP) model)	- The communication line between PWM electric fan and ECU has a short to battery. - The PWM electric fan's own malfunction cannot be identified.						
P0482	PWM Electric Fan Mal-function (Short to GND) (Only for D27DTP (POWER UP) model)	- The communication line between PWM electric fan and ECU has a short to ground. - The PWM electric fan's own malfunction cannot be identified.						
P0483	Fan PWM motor out have short to GND	- Motor out have short to GND						
P0484	Fan PWM Stall motor	- Stall motor						
P0485	Fan PWM motor have over load	- Motor have over load						
P0487	Faulty Maximum Throttle Closing Value	- Causes <ul style="list-style-type: none"> <li>The throttle is not fully closed when learning the full open value after stopping the engine.</li> </ul> - Check pin (refer to P213C). - Sensor specification: Refer to P213C. - Actions <ul style="list-style-type: none"> <li>Check the throttle valve and sensor wiring harnesses.</li> <li>Visually check the unit and replace if necessary.</li> </ul>						
P0488	Throttle Valve - Seized	- The vacuum modulator of throttle valve has an open circuit. - The throttle valve is seized (mechanically). - Check condition for seizing: <ul style="list-style-type: none"> <li>* No error in HFM and EGR</li> <li>* Engine running</li> </ul>						o
P0488	Faulty Maximum Throttle Opening Value	- Causes <ul style="list-style-type: none"> <li>The throttle is not fully open when learning the full open value after initial ignition on.</li> </ul> - Check pin (refer to P213C). - Sensor specification: Refer to P213C. - Actions <ul style="list-style-type: none"> <li>Check the throttle valve and sensor wiring harnesses.</li> <li>Visually check the unit and replace if necessary.</li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0530	Air Conditioner Refrigerant Sensor Supply Power Fault	<ul style="list-style-type: none"> <li>- Causes           <ul style="list-style-type: none"> <li>• There is electric problem in the air conditioner's pressure sensor.</li> </ul> </li> <li>- Check the sensor's specifications and ECU pin.           <ul style="list-style-type: none"> <li>• Power: 5V ..... ECU Pin #B29</li> <li>• Sensor signal ..... ECU Pin #B41</li> <li>• Sensor GND ..... ECU Pin #B36</li> <li>• Actual range: 2.0 kgf/cm<sup>2</sup> (0.75V) ~ 32 kgf/cm<sup>2</sup> (4.5V)</li> <li>• Resistance: 51KΩ (signal terminal and ground)</li> <li>• Output signal               <ul style="list-style-type: none"> <li>0.5V ..... 0.0 kgf/cm<sup>2</sup></li> <li>4.5V ..... 32.0 kgf/cm<sup>2</sup></li> </ul> </li> </ul> </li> <li>- Actions           <ul style="list-style-type: none"> <li>• Check the sensor's resistance and wiring.</li> <li>• Visually check the unit and replace if necessary.</li> </ul> </li> </ul>						
P0532	Air Conditioner Refrigerant Pressure Signal Circuit Short	<ul style="list-style-type: none"> <li>- Causes           <ul style="list-style-type: none"> <li>• There is electric problem in the air conditioner's pressure sensor.</li> </ul> </li> <li>- Check the sensor's specifications and ECU pin.           <ul style="list-style-type: none"> <li>• Power: 5V ..... ECU Pin #B29</li> <li>• Sensor signal ..... ECU Pin #B41</li> <li>• Sensor GND ..... ECU Pin #B36</li> <li>• Actual range: 2.0 kgf/cm<sup>2</sup> (0.75V) ~ 32 kgf/cm<sup>2</sup> (4.5V)</li> <li>• Resistance: 51KΩ (signal terminal and ground)</li> <li>• Output signal               <ul style="list-style-type: none"> <li>0.5V ..... 0.0 kgf/cm<sup>2</sup></li> <li>4.5V ..... 32.0 kgf/cm<sup>2</sup></li> </ul> </li> </ul> </li> <li>- Actions           <ul style="list-style-type: none"> <li>• Check the sensor's resistance and wiring.</li> <li>• Visually check the unit and replace if necessary.</li> </ul> </li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0533	Excessive Air Conditioner Refrigerant Pressure	<ul style="list-style-type: none"> <li>- Causes <ul style="list-style-type: none"> <li>• There is electric problem in the air conditioner's pressure sensor.</li> </ul> </li> <li>- Check the sensor's specifications and ECU pin. <ul style="list-style-type: none"> <li>• Power: 5V ..... ECU Pin #B29</li> <li>• Sensor signal ..... ECU Pin #B41</li> <li>• Sensor GND ..... ECU Pin #B36</li> <li>• Actual range: 2.0 kgf/cm<sup>2</sup> (0.75V) ~ 32 kgf/cm<sup>2</sup> (4.5V)</li> <li>• Resistance: 51KΩ (signal terminal and ground)</li> <li>• Output signal <ul style="list-style-type: none"> <li>0.5V ..... 0.0 kgf/cm<sup>2</sup></li> <li>4.5V ..... 32.0 kgf/cm<sup>2</sup></li> </ul> </li> </ul> </li> <li>- Actions <ul style="list-style-type: none"> <li>• Check the sensor's resistance and wiring.</li> <li>• Visually check the unit and replace if necessary.</li> </ul> </li> </ul>						
P0560	Battery Voltage Malfunction	<ul style="list-style-type: none"> <li>- Malfunction in recognition of system source voltage (A/D converter faults). <ul style="list-style-type: none"> <li>• Less than minimum 8 Volts in 2000 rpm below</li> <li>• Less than 10 Volts in 2000 rpm above.</li> </ul> </li> <li>- Check the battery wiring harness (open, short, poor contact).</li> <li>- Check the battery main relay and fuse.</li> <li>- Check the body ground.</li> <li>- Measure the resistance between body ground and ECU ground. <ul style="list-style-type: none"> <li>• Repair the ECU ground if the resistance is high.</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>	0				0	
P0562	Low Battery Voltage	<ul style="list-style-type: none"> <li>- Malfunction in recognition of system source voltage (Lower than threshold). <ul style="list-style-type: none"> <li>• Less than minimum 8 Volts in 2000 rpm below</li> <li>• Less than 10 Volts in 2000 rpm above.</li> </ul> </li> <li>- Check the battery wiring harness (open, short, poor contact).</li> <li>- Check the battery main relay and fuse.</li> <li>- Check the body ground.</li> <li>- Measure the resistance between body ground and ECU ground. <ul style="list-style-type: none"> <li>• Repair the ECU ground if the resistance is high.</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>	0				0	

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0563	High Battery Voltage	<ul style="list-style-type: none"> <li>- Malfunction in recognition of system source voltage (Higher than threshold).           <ul style="list-style-type: none"> <li>• More than minimum 16 Volts in 2000 rpm below</li> </ul> </li> <li>- Check the battery wiring harness (open, short, poor contact).</li> <li>- Check the alternator.</li> <li>- Check the body ground.</li> <li>- Measure the resistance between body ground and ECU ground.           <ul style="list-style-type: none"> <li>• Repair the ECU ground if the resistance is high.</li> </ul> </li> <li>- Replace the ECU if required.</li> </ul>	0					0
P0571	Brake Pedal Switch Fault	<ul style="list-style-type: none"> <li>- The brake pedal switch or light switch is faulty.           <ul style="list-style-type: none"> <li>• Brake pedal switch: Normal Close (NC)</li> <li>• Light switch: Normal Open (NO)</li> <li>• When operating the brake switch, one signal (NO) is sent to auto cruise and the other (NC) is sent to brake lamp.</li> </ul> </li> <li>- Check the brake and light switch wiring harness.</li> <li>- Check the supply voltage to brake and light switch (12 V).</li> <li>- Check the brake and light switch for contact.</li> <li>- Check the ECU wiring harness (short, poor contact).</li> <li>- Replace the ECU if required.</li> </ul>						
P0602	Faulty Vehicle Speed Sensor Coding	<ul style="list-style-type: none"> <li>- The vehicle signal is inputted via CAN communication without ESP or TCCU.</li> <li>- The CAN communication between units is malfunctioning.</li> </ul>						
P0606	ECU Watchdog Fault	<ul style="list-style-type: none"> <li>- The ECU is defective.</li> <li>- Check the chassis ground wiring harness.</li> <li>- Check the ECU.</li> <li>- Replace the ECU if required.</li> </ul>						0

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0608	Faulty ABS/ESP Coding	- The ABS/ESP variant coding is faulty. - The CAN communication is malfunctioning.						
P0611	No Data for C3I	- C3I • There is no C3I data in ECU or the checksum is faulty.						o
P0612	Internal Error in C3I Data	- C3I • The error is occurred while sending C3I data in ECU to RAM.						
P0613	Faulty TCU Coding	- The TCU variant coding is faulty. - The CAN communication between units is malfunctioning.						
P0614	TCCU Coding Fault	- Occurred if TCCU variant coding is faulty. - Occurred when there is CAN communication error between units.						
P0618	Multi calibration not performed	- Perform multi calibration again.						
P0619	Multi calibration performing error	- Perform multi calibration again.						
P062D (former P1611)	Injector Bank #1 Malfunction - Low Voltage  4-cylinder engine : 1 <sup>nd</sup> and 4 <sup>th</sup> cylinders 5-cylinder engine : 1 <sup>nd</sup> , 4 <sup>th</sup> and 3 <sup>rd</sup> cylinders	- Malfunction of injector (#1, #4, #3) circuit (Low): Short to Ground or to Battery. - Operating voltage: 6 ~ 18 V - Check the injector bank #1: Open and poor contact - Check if the trouble recurs with the injectors removed and the ignition key "OFF". • If recurred, check the injector and ECU wiring harness. - Check if the trouble recurs while installing the injectors one by one with the ignition key "ON". • If recurred, replace the injector (perform C2I/C3I coding after replacement). • Check the other injectors with same manner. - Check the ECU wiring harness. - Replace the ECU if required.						o
P062E (former P1618)	Injector Bank #2 Malfunction - Low Voltage  4-cylinder engine : 2 <sup>nd</sup> and 3 <sup>rd</sup> cylinders 5-cylinder engine : 2 <sup>nd</sup> and 5 <sup>th</sup> cylinders	- Malfunction of injector (#2, #5) circuit (Low): Short to Ground or to Battery. - Operating voltage: 6 ~ 18 V - Check the injector bank #2: Open and poor contact - Check if the trouble recurs with the injectors removed and the ignition key "OFF". • If recurred, check the injector and ECU wiring harness. - Check if the trouble recurs while installing the injectors one by one with the ignition key "ON". • If recurred, replace the injector (perform C2I/C3I coding after replacement). • Check the other injectors with same manner. - Check the ECU wiring harness. - Replace the ECU if required.						o

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P062F	Multi calibration memory error	- Perform multi calibration again.						
P0630	Variant Coding is not done	- Variant coding is not done					o	
P0631	Variant Coding writing error	- Variant coding writing error					o	
P0633	Immobilizer Fault (refer to immobilizer section)	- Key memory is not available (permissible - 5). - Perform the immobilizer coding again. - Check the ECU wiring harness. - Check the immobilizer unit for open and short or check the supply voltage. - Check the immobilizer antenna and transponder for damage. - Replace the ECU if required.						
P0641	ECU Supply Voltage 1 Fault (5 V)	- Malfunction reference supply voltage from ECU • Supply voltage: 5 V - Check the supply voltage to each sensor • Supply voltage (5 V): accelerator pedal sensor 1, HFM sensor, rail pressure sensor, booster pressure sensor, cam sensor - Check the wiring harnesses. - Replace the ECU if required.						
P0642	ECU Supply Voltage 1 Fault - Low (5 V)	- Malfunction reference supply voltage from ECU • Supply voltage: 5 V - Check the supply voltage to each sensor • Supply voltage (5 V): accelerator pedal sensor 1, HFM sensor, rail pressure sensor, booster pressure sensor, cam sensor - Check the wiring harnesses. - Replace the ECU if required.						
P0643	ECU Supply Voltage 1 Fault - High (5 V)	- Malfunction reference supply voltage from ECU • Supply voltage: 5 V - Check the supply voltage to each sensor • Supply voltage (5 V): accelerator pedal sensor 1, HFM sensor, rail pressure sensor, booster pressure sensor, cam sensor - Check the wiring harnesses. - Replace the ECU if required.						
P0649	Diag Lamp Drive Open Circuit	Open circuit						
P0650	Diag Lamp Drive Short to BATT	Short to batt						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0651	ECU Supply Voltage 2 Fault (5 V)	<ul style="list-style-type: none"> <li>- Malfunction reference supply voltage from ECU           <ul style="list-style-type: none"> <li>• Supply voltage: 5 V</li> </ul> </li> <li>- Check the supply voltage to each sensor           <ul style="list-style-type: none"> <li>• Supply voltage (5 V): accelerator pedal sensor 1, HFM sensor, rail pressure sensor, booster pressure sensor, cam sensor</li> </ul> </li> <li>- Check the wiring harnesses.</li> <li>- Replace the ECU if required.</li> </ul>			o		o	o
P0652	ECU Supply Voltage 2 Fault - Low (5 V)	<ul style="list-style-type: none"> <li>- Malfunction reference supply voltage from ECU           <ul style="list-style-type: none"> <li>• Supply voltage: 5 V</li> </ul> </li> <li>- Check the supply voltage to each sensor           <ul style="list-style-type: none"> <li>• Supply voltage (5 V): accelerator pedal sensor 1, HFM sensor, rail pressure sensor, booster pressure sensor, cam sensor</li> </ul> </li> <li>- Check the wiring harnesses.</li> <li>- Replace the ECU if required.</li> </ul>			o		o	o
P0653	ECU Supply Voltage 2 Fault - High (5 V)	<ul style="list-style-type: none"> <li>- Malfunction reference supply voltage from ECU           <ul style="list-style-type: none"> <li>• Supply voltage: 5 V</li> </ul> </li> <li>- Check the supply voltage to each sensor           <ul style="list-style-type: none"> <li>• Supply voltage (5 V): accelerator pedal sensor 1, HFM sensor, rail pressure sensor, booster pressure sensor, cam sensor</li> </ul> </li> <li>- Check the wiring harnesses.</li> <li>- Replace the ECU if required.</li> </ul>			o		o	o
P066A	Internal malfunction in #1 glow plug controller	<ul style="list-style-type: none"> <li>- Cylinder #1 (Glow Plug #1)</li> <li>- Details: refer to P2673.</li> </ul>						
P066B	Internal short in #1 glow plug controller	<ul style="list-style-type: none"> <li>- Cylinder #1 (Glow Plug #1)</li> <li>- Details: refer to P2673.</li> </ul>						
P066C	Internal malfunction in #2 glow plug controller	<ul style="list-style-type: none"> <li>- Cylinder #2 (Glow Plug #2)</li> <li>- Details: refer to P2673.</li> </ul>						
P066D	Internal short in #2 glow plug controller	<ul style="list-style-type: none"> <li>- Cylinder #2 (Glow Plug #2)</li> <li>- Details: refer to P2673.</li> </ul>						
P066E	Internal malfunction in #3 glow plug controller	<ul style="list-style-type: none"> <li>- Cylinder #3 (Glow Plug #3)</li> <li>- Details: refer to P2673.</li> </ul>						
P066F	Internal short in #3 glow plug controller	<ul style="list-style-type: none"> <li>- Cylinder #3 (Glow Plug #3)</li> <li>- Details: refer to P2673.</li> </ul>						
P0670	Defective power supply of glow plug controller	<ul style="list-style-type: none"> <li>- Details: refer to P2673.</li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduc-tion (max.50%)	Torque Reduc-tion (max.20%)	Delayed Engine Stop	Immedi-ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0671	#3 Glow Plug Fault - Open	<ul style="list-style-type: none"> <li>The glow plug circuit is open.</li> <li>Check the communication line between ECU and each glow plug.</li> <li>Check each glow plug wiring harness.</li> <li>Check the resistance of each glow plug: below 1 Ω.</li> <li>Check each glow plug relay.</li> <li>Check the ECU wiring harness.</li> <li>Replace the ECU if required.</li> </ul>						
P0671	#3 Glow Plug - Open Circuit (applied for D27DT engine, Not applied for AQGS model)	<p>D27DT: Preheat control relay</p> <ul style="list-style-type: none"> <li>The glow plug has an open circuit.</li> <li>Check the communication line between ECU and glow plug.</li> <li>Check the glow plug wiring.</li> <li>Check the resistance of glow plug.</li> <li>Check the relay of glow plug.</li> <li>Check the ECU wiring harness.</li> <li>Replace the ECU if required.</li> </ul> <p>D27DTP: AQGS unit</p> <ul style="list-style-type: none"> <li>NGK glow module (AQGS: Advanced Quick Glowing System)</li> <li>Its condition is sent to ECU through CAN after detected by AQGS.</li> <li>The AQGS has an electrical problem.</li> <li>Diagnosis criteria of AQGS <ul style="list-style-type: none"> <li>Plug short circuit: voltage &gt; 6V, current = 0A</li> <li>Plug short circuit (GND): voltage = 0V</li> <li>Plug short circuit (batt.): voltage = battery voltage</li> <li>FET malfunction, FET short circuit (GND): voltage = 0V, current = 0A</li> <li>Input voltage fault: 6V &lt; input voltage &lt; 16V</li> <li>Communication fault: Abnormal data for over 1 second</li> </ul> </li> <li>Actions <ul style="list-style-type: none"> <li>Check the glow plug for malfunction (measuring its resistance).</li> <li>Check the connector and wiring.</li> <li>Visually check the glow plug.</li> <li>Replace the glow plug if required.</li> <li>Check the CAN line.</li> <li>Check the IG1 power.</li> <li>Check the battery power.</li> </ul> </li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduc- tion (max.50%)	Torque Reduc- tion (max.20%)	Delayed Engine Stop	Immedi- ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0672	#4 Glow Plug Fault - Open	<ul style="list-style-type: none"> <li>The glow plug circuit is open.</li> <li>Check the communication line between ECU and each glow plug.</li> <li>Check each glow plug wiring harness.</li> <li>Check the resistance of each glow plug: below 1Ω.</li> <li>Check each glow plug relay.</li> <li>Check the ECU wiring harness.</li> <li>Replace the ECU if required.</li> </ul>						
P0672	#4 Glow Plug - Open Circuit  (applied for D27DT engine, Not applied for AQGS model)	<p>D27DT: Preheat control relay</p> <ul style="list-style-type: none"> <li>The glow plug has an open circuit.</li> <li>Check the communication line between ECU and glow plug.</li> <li>Check the glow plug wiring.</li> <li>Check the resistance of glow plug.</li> <li>Check the relay of glow plug.</li> <li>Check the ECU wiring harness.</li> <li>Replace the ECU if required.</li> </ul> <p>D27DTP: AQGS unit</p> <ul style="list-style-type: none"> <li>NGK glow module (AQGS: Advanced Quick Glowing System)</li> <li>Its condition is sent to ECU through CAN after detected by AQGS.</li> <li>The AQGS has an electrical problem.</li> <li>Diagnosis criteria of AQGS <ul style="list-style-type: none"> <li>Plug short circuit: voltage &gt; 6V, current = 0A</li> <li>Plug short circuit (GND): voltage = 0V</li> <li>Plug short circuit (batt.): voltage = battery voltage</li> <li>FET malfunction, FET short circuit (GND): voltage = 0V, current = 0A</li> <li>Input voltage fault: 6V &lt; input voltage &lt; 16V</li> <li>Communication fault: Abnormal data for over 1 second</li> </ul> </li> <li>Actions <ul style="list-style-type: none"> <li>Check the glow plug for malfunction (measuring its resistance).</li> <li>Check the connector and wiring.</li> <li>Visually check the glow plug.</li> <li>Replace the glow plug if required.</li> <li>Check the CAN line.</li> <li>Check the IG1 power.</li> <li>Check the battery power.</li> </ul> </li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduc- tion (max.50%)	Torque Reduc- tion (max.20%)	Delayed Engine Stop	Immedi- ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0673	#5 Glow Plug Fault - Open	<ul style="list-style-type: none"> <li>- The glow plug circuit is open.</li> <li>- Check the communication line between ECU and each glow plug.</li> <li>- Check each glow plug wiring harness.</li> <li>- Check the resistance of each glow plug: below 1 Ω.</li> <li>- Check each glow plug relay.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>						
P0673	#5 Glow Plug - Open Circuit  (applied for D27DT engine, Not applied for AQGS model)	<p>D27DT: Preheat control relay</p> <ul style="list-style-type: none"> <li>- The glow plug has an open circuit.</li> <li>- Check the communication line between ECU and glow plug.</li> <li>- Check the glow plug wiring.</li> <li>- Check the resistance of glow plug.</li> <li>- Check the relay of glow plug.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul> <p>D27DTP: AQGS unit</p> <ul style="list-style-type: none"> <li>- NGK glow module (AQGS: Advanced Quick Glowing System)</li> <li>- Its condition is sent to ECU through CAN after detected by AQGS.</li> <li>- The AQGS has an electrical problem.</li> <li>- Diagnosis criteria of AQGS <ul style="list-style-type: none"> <li>• Plug short circuit: voltage &gt; 6V, current = 0A</li> <li>• Plug short circuit (GND): voltage = 0V</li> <li>• Plug short circuit (batt.): voltage = battery voltage</li> <li>• FET malfunction, FET short circuit (GND): voltage = 0V, current = 0A</li> <li>• Input voltage fault: 6V &lt; input voltage &lt; 16V</li> <li>• Communication fault: Abnormal data for over 1 second</li> </ul> </li> <li>- Actions <ul style="list-style-type: none"> <li>• Check the glow plug for malfunction (measuring its resistance).</li> <li>• Check the connector and wiring.</li> <li>• Visually check the glow plug.</li> <li>• Replace the glow plug if required.</li> <li>• Check the CAN line.</li> <li>• Check the IG1 power.</li> <li>• Check the battery power.</li> </ul> </li> </ul>						

Modification basis	
Application basis	
Affected VIN	

 ECU-GASOLIN  
ECU-DIESEL  
BRAKE  
AIR-BAG  
CCCS  
FATC  
FFH  
P/TRUNK  
TC  
TCU  
STICS  
RAIN SENSOR  
TGS LEVER

DTC	Trouble	Help	Torque Reduc- tion (max.50%)	Torque Reduc- tion (max.20%)	Delayed Engine Stop	Immedi- ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0674	#1 Glow Plug Fault - Open	<ul style="list-style-type: none"> <li>- The glow plug circuit is open.</li> <li>- Check the communication line between ECU and each glow plug.</li> <li>- Check each glow plug wiring harness.</li> <li>- Check the resistance of each glow plug: below 1 Ω.</li> <li>- Check each glow plug relay.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>						
P0674	#1 Glow Plug - Open Circuit	<p>D27DT: Preheat control relay</p> <ul style="list-style-type: none"> <li>- The glow plug has an open circuit.</li> <li>- Check the communication line between ECU and glow plug.</li> <li>- Check the glow plug wiring.</li> <li>- Check the resistance of glow plug.</li> <li>- Check the relay of glow plug.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul> <p>D27DTP: AQGS unit</p> <ul style="list-style-type: none"> <li>- NGK glow module (AQGS: Advanced Quick Glowing System)</li> <li>- Its condition is sent to ECU through CAN after detected by AQGS.</li> <li>- The AQGS has an electrical problem.</li> <li>- Diagnosis criteria of AQGS <ul style="list-style-type: none"> <li>• Plug short circuit: voltage &gt; 6V, current = 0A</li> <li>• Plug short circuit (GND): voltage = 0V</li> <li>• Plug short circuit (batt.): voltage = battery voltage</li> <li>• FET malfunction, FET short circuit (GND): voltage = 0V, current = 0A</li> <li>• Input voltage fault: 6V &lt; input voltage &lt; 16V</li> <li>• Communication fault: Abnormal data for over 1 second</li> </ul> </li> <li>- Actions <ul style="list-style-type: none"> <li>• Check the glow plug for malfunction (measuring its resistance).</li> <li>• Check the connector and wiring.</li> <li>• Visually check the glow plug.</li> <li>• Replace the glow plug if required.</li> <li>• Check the CAN line.</li> <li>• Check the IG1 power.</li> <li>• Check the battery power.</li> </ul> </li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0675	#2 Glow Plug Fault - Open	<ul style="list-style-type: none"> <li>- The glow plug circuit is open.</li> <li>- Check the communication line between ECU and each glow plug.</li> <li>- Check each glow plug wiring harness.</li> <li>- Check the resistance of each glow plug: below 1 Ω.</li> <li>- Check each glow plug relay.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul>						
P0675	#2 Glow Plug - Open Circuit (applied for D27DT engine, Not applied for AQGS model)	<p>D27DT: Preheat control relay</p> <ul style="list-style-type: none"> <li>- The glow plug has an open circuit.</li> <li>- Check the communication line between ECU and glow plug.</li> <li>- Check the glow plug wiring.</li> <li>- Check the resistance of glow plug.</li> <li>- Check the relay of glow plug.</li> <li>- Check the ECU wiring harness.</li> <li>- Replace the ECU if required.</li> </ul> <p>D27DTP: AQGS unit</p> <ul style="list-style-type: none"> <li>- NGK glow module (AQGS: Advanced Quick Glowing System)</li> <li>- Its condition is sent to ECU through CAN after detected by AQGS.</li> <li>- The AQGS has an electrical problem.</li> <li>- Diagnosis criteria of AQGS <ul style="list-style-type: none"> <li>• Plug short circuit: voltage &gt; 6V, current = 0A</li> <li>• Plug short circuit (GND): voltage = 0V</li> <li>• Plug short circuit (batt.): voltage = battery voltage</li> <li>• FET malfunction, FET short circuit (GND): voltage = 0V, current = 0A</li> <li>• Input voltage fault: 6V &lt; input voltage &lt; 16V</li> <li>• Communication fault: Abnormal data for over 1 second</li> </ul> </li> <li>- Actions <ul style="list-style-type: none"> <li>• Check the glow plug for malfunction (measuring its resistance).</li> <li>• Check the connector and wiring.</li> <li>• Visually check the glow plug.</li> <li>• Replace the glow plug if required.</li> <li>• Check the CAN line.</li> <li>• Check the IG1 power.</li> <li>• Check the battery power.</li> </ul> </li> </ul>						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduc- tion (max.50%)	Torque Reduc- tion (max.20%)	Delayed Engine Stop	Immedi- ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P067A	Internal malfunction in #4 glow plug controller	- Cylinder #4 (Glow Plug #4) - Details: refer to P2673.						
P067B	Internal short in #4 glow plug controller	- Cylinder #4 (Glow Plug #4) - Details: refer to P2673.						
P067C	Internal malfunction in #5 glow plug controller	- Cylinder #5 (Glow Plug #5) - Details: refer to P2673.						
P067D	Internal short in #5 glow plug controller	- Cylinder #5 (Glow Plug #5) - Details: refer to P2673.						
P0683	Defective CAN communication of glow plug controller	- GCU's CAN signal is intermittently defective.						
P0685	Main Relay Malfunction	- The main relay is unexpectedly high/low state (ECU is supplied after 3 seconds). - Relay resistance: $92 \pm 9 \Omega$ (at 20°C) - Check the relay wiring harness (open, short and poor contact). - If the forced operation is not available, replace the ECU.						
P0697	ECU Supply Voltage Fault (2.5 V)	- Malfunction reference supply voltage from ECU • Supply voltage: 2.5 V - Check the supply voltage to each sensor • Supply voltage (2.55 V): accelerator pedal sensor 2 - Check the wiring harnesses. - Replace the ECU if required.						
P0698	ECU Supply Voltage Fault - Low (2.5 V)	- Malfunction reference supply voltage from ECU • Supply voltage: 2.5 V - Check the supply voltage to each sensor • Supply voltage (2.5 V): accelerator pedal sensor 2 - Check the wiring harnesses. - Replace the ECU if required.						
P0699	ECU Supply Voltage Fault - High (2.5 V)	- Malfunction reference supply voltage from ECU • Supply voltage: 2.5 V - Check the supply voltage to each sensor • Supply voltage (2.55 V): accelerator pedal sensor 2 - Check the wiring harnesses. - Replace the ECU if required.						
P0700	TCU Signal Fault	- The communication between ECU and TCU is faulty. - Check the communication line between ECU and TCU. - Replace the ECU if required.						

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduction (max.50%)	Torque Reduction (max.20%)	Delayed Engine Stop	Immediately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P0704	Clutch switch malfunction	<ul style="list-style-type: none"> <li>The clutch switch is faulty (Manual Transmission Only).</li> <li>Check the switch wiring harness.</li> <li>Check the switch supply voltage and operations.</li> <li>Replace the ECU if required.</li> </ul>						
P0805	Neutral Signal Input Malfunction (Only for D27DT M/T model)	<ul style="list-style-type: none"> <li>The neutral signal of M/T is sent to CAN cluster which is then sent to ECU via CAN communication.</li> <li>The ECU cannot detect whether signal is missing due to the malfunction in neutral signal and wiring or due to the line malfunction.</li> <li>Check the wiring related to neutral switch.</li> </ul>						
P1102	HFM Sensor - High Characteristic Value (Only for D27DT model)	<ul style="list-style-type: none"> <li>The characteristic value of HFM sensor is over the specified value (not wiring malfunction).</li> </ul>						
P1103	HFM Sensor - Low Characteristic Value (Only for D27DT model)	<ul style="list-style-type: none"> <li>The characteristic value of HFM sensor is below the specified value (not wiring malfunction).</li> </ul>						
P1105	Barometric Sensor Circuit Short	<ul style="list-style-type: none"> <li>Out of range about barometric sensor (over voltage).</li> <li>Actual barometric pressure vs. Output voltages. <ul style="list-style-type: none"> <li>15 Kpa: 0 V      35 Kpa: 1.0 V</li> <li>55 Kpa: 2.0 V      80 Kpa: 3.0 V</li> <li>100 Kpa: 4.0 V      110 Kpa: 4.5 V</li> </ul> </li> <li>Replace the ECU.</li> </ul>						o
P1106	Booster Pressure Sensor Malfunction	<ul style="list-style-type: none"> <li>Out of range of supply voltages about boost pressure sensor at Ignition key-On and Engine Stop (Higher than specified values).</li> <li>Check the supply voltage to sensor.</li> <li>Actual boost pressure vs. Output voltages. <ul style="list-style-type: none"> <li>Raw Signal Range: 0.545 ~ 2.490 bar</li> <li>0.4 bar: 0.6120 V</li> <li>1.4 bar: 2.6520 V</li> <li>2.4 bar: 4.6920 V</li> </ul> </li> <li>Check the sensor wiring harness (open, poor contact).</li> <li>Visually check sensor and replace if required.</li> <li>Replace the ECU if required.</li> <li>Check whether existing or not about turbo boosting control malfunction (P1235) simultaneously.</li> <li>If there is turbo boost control fault, Should be checked followings also; <ul style="list-style-type: none"> <li>Leakage before turbo system</li> <li>Vacuum pump malfunction</li> <li>Waste gate' solenoid valve</li> <li>Turbo charger system defect or malfunction itself</li> <li>Air inlet restriction</li> <li>Exhaust system restriction</li> </ul> </li> </ul>						o

Modification basis	
Application basis	
Affected VIN	

DTC	Trouble	Help	Torque Reduc-tion (max.50%)	Torque Reduc-tion (max.20%)	Delayed Engine Stop	Immedi-ately Engine Stop	Limp Home Mode	Engine Check Warning Lamp
P1107	Barometric Sensor Circuit Short/GND Short	<ul style="list-style-type: none"> <li>- Out of range about barometric sensor (short to ground).</li> <li>- Actual barometric pressure vs. Output voltages. <ul style="list-style-type: none"> <li>• 15 Kpa: 0 V 35 Kpa: 1.0 V</li> <li>• 55 Kpa: 2.0 V 80 Kpa: 3.0 V</li> <li>• 100 Kpa: 4.0 V 110 Kpa: 4.5 V</li> </ul> </li> <li>- Replace the ECU.</li> </ul>						
P1108	Barometric Sensor Circuit Short	<ul style="list-style-type: none"> <li>- Out of range about barometric sensor (short to B+).</li> <li>- Actual barometric pressure vs. Output voltages. <ul style="list-style-type: none"> <li>• 15 Kpa: 0 V 35 Kpa: 1.0 V</li> <li>• 55 Kpa: 2.0 V 80 Kpa: 3.0 V</li> <li>• 100 Kpa: 4.0 V 110 Kpa: 4.5 V</li> </ul> </li> <li>- Replace the ECU.</li> </ul>						
P1109	Booster Pressure Sensor Initial Check Fault	<ul style="list-style-type: none"> <li>- Implausible signal values or range about boost pressure sensor at Engine running condition (Higher than specified values).</li> <li>- Check the supply voltage to sensor.</li> <li>- Actual boost pressure vs. Output voltages <ul style="list-style-type: none"> <li>• Raw Signal Range: 0.545 ~ 2.490 bar</li> <li>• 0.4 bar: 0.6120 V</li> <li>• 1.4 bar: 2.6520 V</li> <li>• 2.4 bar: 4.6920 V</li> </ul> </li> <li>- Check the sensor wiring harness (open, poor contact).</li> <li>- Visually check sensor and replace if required.</li> <li>- Replace the ECU if required.</li> <li>- Check whether existing or not about turbo boosting control malfunction (P1235) simultaneously.</li> <li>- If there is turbo boost control fault, Should be checked followings also; <ul style="list-style-type: none"> <li>• Leakage before turbo system</li> <li>• Vacuum pump malfunction</li> <li>• Waste gate' solenoid valve</li> <li>• Turbo charger system defect or malfunction itself</li> <li>• Air inlet restriction</li> <li>• Exhaust system restriction</li> </ul> </li> </ul>						

Modification basis	
Application basis	
Affected VIN	