

TGS LEVER

0000-00

INDEX

TGS LEVER

DIAGNOSIS

1. TGS LEVER.....	3
-------------------	---

TGS LEVER

0000-00

DIAGNOSIS

1. TGS LEVER

DTC	Malfunction	Help tips
P1000-1	Defective program memory	Cause: The calculated checksum value is not consistent with the stored checksum value. Symptom: - Solenoid valve is inoperative. - Backup lamp is OFF. - CAN bus is OFF. - All shift lever position indicators are OFF. Action: - Reset the unit by cycling the ignition switch (OFF → ON) several times.
P1000-2	Defective data memory	Cause: The malfunction is occurred during the RAM memory test with the ignition ON. Symptom: - Solenoid valve is inoperative. - Backup lamp: OFF - CAN bus: OFF - All shift lever position indicators: OFF Action: - If the malfunction stays after turning the ignition switch from OFF to ON, replace the TGS lever.
P1000-3	Faulty MCU reset	Cause: The malfunction is occurred during the microprocessor test with the ignition ON. Symptom: - Solenoid valve is inoperative. - Backup lamp is OFF. - CAN bus is OFF. - All shift lever position indicators are OFF. Action: - Reset the unit by cycling the ignition switch (OFF → ON) several times.
P1000-4	Faulty MCU data process	
P1000-5	Faulty MCU watchdog function	
P1000-6	Too long MCU data throughput time	
P1750-2	Low battery voltage	Cause: The battery voltage is low. (Specified value: less than 8.0 ± 0.3 V for 50 ms) Symptom: - All shift lever position indicators are OFF. Action: - The operation is automatically resumed if the battery voltage is over 8.7 ± 0.3 V for 50 ms. - Check the shift lever connector and power line for contact.
P1817-1	Faulty backup lamp operating current	Cause: The operating current is over 14 ~ 36 A for 50 ms when the backup lamp is in ON condition. Symptom: - Backup lamp is OFF. - Current shift lever indicator is flashing. - Indicator "R" is flashing in "R" position. Action: - Check the input and output wirings of backup lamp for open and short.
P1832-1	Faulty solenoid operating current	Cause: The solenoid valve operating current is over 3 ~ 5 A when the solenoid is operating. Symptom: - Solenoid valve is OFF. - Current shift lever indicator is flashing. Action: - The operation is automatically resumed since the interior temperature is normally within the solenoid operating temperature range. If the problem stays, check the power to the shift lever.

Modification basis	
Application basis	
Affected VIN	

DTC	Malfunction	Help tips
P1833-2	Open solenoid valve circuit	Cause: The solenoid valve circuit is open or short to battery for 50 ms when the solenoid valve is OFF. Symptom: - Solenoid valve is OFF. - Current shift lever indicator is flashing. Action: - Check the power terminal to the shift lever.
P1856-1	Short shift lever position signal (to B+)	Cause: The shift lever position sensor or the power supply is malfunctioning. Symptom: - All shift lever position indicators are flashing.. - The incorrect lever position signal is transmitted through the CAN line. Action: - The operation is automatically resumed if the fault is not detected for 100 ms. - Check the power supply terminal to the shift lever.
P1856-2	Open or short shift lever position signal (to GND)	Cause: The shift lever position sensor is open or short to ground. Symptom: - All shift lever position indicators: flashing. - The incorrect lever position signal is transmitted through the CAN line. Action: - The operation is automatically resumed if the fault is not detected for 100 ms. - Check the power supply terminal to the shift lever.
P1856-3	Abnormal shift lever position signal	Cause: The shift lever position sensor signal is incorrect. Symptom: - All shift lever position indicators are flashing. - The incorrect lever position signal is transmitted through the CAN line. Action: - The operation is automatically resumed if the fault is not detected for 100 ms. - Check the power supply terminal to the shift lever.
P1856-4	Incorrect shift lever position sensor coding	Cause: The calibration value of shift lever position sensor is not stored or not consistent with the stored value. Symptom: - All shift lever position indicators are flashing. - The incorrect lever position signal is transmitted through the CAN line. Action: - Reset the unit by cycling the ignition switch (OFF → ON) several times. - Check the shift lever and replace it if necessary.
P1860-2	Faulty vehicle speed signal	Cause: The vehicle speed is detected as 300 km/h. Symptom: - The gear is shifted as for the vehicle speed is 0 km/h. - Current shift lever position indicator is flashing. Action: - The operation is automatically resumed if the fault is not detected. * For the shift lever, the vehicle speed data is needed to the solenoid valve operation for R/P lock and N lock function.
P1875-3	Faulty CAN bus OFF signal	Cause: The CAN bus OFF condition of the CAN controller is detected for 3 times in the unit. Symptom: - Cannot send the CAN message. - Current shift lever position indicator is flashing. Action: - Check the CAN communication line for open or short. - Check the shift lever and replace it if necessary. * CAN Bus OFF: The status that the CAN communication is totally interrupted if there is an error in the sent/received data through the CAN communication in the unit.

DTC	Malfunction	Help tips
P1876-1	Abnormal CAN communication (vehicle speed)	Cause: There is no vehicle speed signal via CAN communication for 500 ms. Symptom: - The gear is shifted as for the vehicle speed is 0 km/h. - Current shift lever position indicator is flashing. Action: - Check the CAN communication line.
P1910-1	High battery voltage	Cause: The battery voltage is too high. (Specified value: Over 16.3 ± 0.3 V for 50 ms) Symptom: - All shift lever position indicators: OFF Action: - The operation is automatically resumed if the battery voltage is over 16.3 ± 0.3 V for 50 ms. - Check the shift lever power supply line.
P1912-1	Open/Short shift lever tip switch signal (to B+)	Cause: The shift lever tip switch signal is open or short to B+. Symptom: - Indicator "M" is flashing due to malfunction when the shift lever is in manual mode position. - If the shift lever is not in "M" position, the malfunction is overridden. Action: - The operation is automatically resumed if the fault is not detected for 50 ms. - Check the shift lever tip switch.
P1912-2	Short shift lever tip switch signal s(to GND)	Cause: The shift lever tip switch signal is open or short to ground. Symptom: - Indicator "M" is flashing due to malfunction when the shift lever is in the manual mode position. - If the shift lever is not in "M", the malfunction is overridden. Action: - The operation is automatically resumed if the fault is not detected for 50 ms. - Check the shift lever tip switch.
P1912-3	Abnormal shift lever tip switch signal	Cause: The shift lever tip switch signal is faulty. Symptom: - Indicator "M" is flashing due to malfunction when the shift lever is in the manual mode position. - If the shift lever is not in "M" position, the malfunction is overridden. Action: - The operation is automatically resumed if the fault is not detected for 50 ms. - Check the shift lever tip switch.
P1912-4	Open/Short steering wheel tip switch signal (to B+)	Cause: The steering wheel tip switch signal is open or short to B+. Symptom: - Indicator "M" is flashing due to malfunction when the shift lever is in the manual mode position. - If the shift lever is not in "M" position, the malfunction is overridden. Action: - The operation is automatically resumed if the fault is not detected for 50 ms. - Check the steering wheel's tip switch.
P1912-5	Open/Short steering wheel tip switch signal (to GND)	Cause: The steering wheel tip switch signal is open or short to ground. Symptom: - Indicator "M" is flashing due to malfunction when the shift lever is in the manual mode position. - If the shift lever is not in "M" position, the malfunction is overridden. Action: - The operation is automatically resumed if the fault is not detected for 50 ms. - Check the steering wheel tip switch.

Modification basis	
Application basis	
Affected VIN	

DTC	Malfunction	Help tips
P1912-6	Abnormal steering wheel tip switch signal	Cause: The steering wheel tip switch signal is faulty. Symptom: - Indicator "M" is flashing due to malfunction when the shift lever is in the manual mode position. - If the shift lever is not in "M" position, the malfunction is overridden. Action: - The operation is automatically resumed if the fault is not detected for 50 ms. - Check the steering wheel tip switch.
P1912-7	Defective tip switch	Cause: The manual mode switch operates for 50 ms when the shift lever is P, R or N positions. Symptom: - Indicator "M" flashes if the shift lever is in D. - The mode is recognized as the manual mode even if the shift lever is in "D" position. Action: - The operation is automatically resumed if the fault is not detected for 50 ms and the shift lever is in P, R or N positions.
P1927-8	Faulty TCU shift	Check the TCU if there is errors related to the A/T shift.
P1928-4	Defective TCU CAN communication	Cause: The up/down shift command is not delivered to the TCU (faulty tip switch). - There is no CAN signal for 500 ms. Symptom: - Indicator "M" is flashing due to malfunction when the shift lever is in the manual mode position. - If the shift lever is not in "M" position, the malfunction is overridden. Action: - Check the CAN communication line.