


Connector Terminal Views

308. PCM

[Pin Numbering](#)[Menu](#)[Circuit Index](#)

Connector A


- BLK/WHT
- Right side of engine compartment
- On right engine compartment wire harness (front of engine compartment)



- | | |
|--|---|
| 1. WHT (Fuse 29 – Under-dash) | 25. ORN (VCC4) |
| 2. PNK (Interlock System) | 26. WHT (ETCS (Electronic Throttle Control System)) |
| 3. LT GRN (Starting System) | 27. GRN (SG4) |
| 4. WHT (Fans) | 28. PNK (Starting System) |
| 5. PUR (Fans) | 29. BLU (ETCS (Electronic Throttle Control System)) |
| 6. GRN (PGM-FI System) | 30. BLU (Vehicle Speed Signal) |
| 7. BRN (Cruise Control) | 31. LT BLU (PCM Power and Grounds) |
| 8. LT GRN (Brake Pedal Position) | 32. BRN (DLC (Data Link Connector)) |
| 9. BLK (PGM-FI System) | 33. — |
| 10. ORN (Charging System) | 34. — |
| 11. BRN (Fuel Supply System) | 35. — |
| 12. BLU (Engine Mount Control System) | 36. BLU (A/T Gear Position Indicator) |
| 13. RED (Idle Control System) | 37. GRN (Fuel Supply System) |
| 14. — | 38. PNK (Idle Control System) |
| 15. — | 39. LT GRN (EVAP System) |
| 16. GRN (A/T Park Position) | 40. RED (PGM-FI System) |
| 17. — | 41. BRN (Immobilizer System) |
| 18. PUR (ETCS (Electronic Throttle Control System)) | 42. LT BLU (Fuel Supply System) |
| 19. LT GRN (ETCS (Electronic Throttle Control System)) | 43. PNK (Fuel Supply System) |
| 20. RED (PGM-FI System) | 44. GRY (DLC (Data Link Connector)) |
| 21. PUR (PGM-FI System) | 45. — |
| 22. LT GRN (EVAP System) | 46. LT GRN (Immobilizer System) |
| 23. — | 47. PUR (A/T Gear Position Indicator) |
| 24. RED (ETCS (Electronic Throttle Control System)) | 48. WHT (F-CAN (High)) |
| | 49. RED (F-CAN (Low)) |

Connector B

- BLK/GRY
- Right side of engine compartment
- On engine wire harness (center to right side)



- | | |
|---|---|
| 1. BLK (G101) | 26. RED/BLU (ETCS (Electronic Throttle Control System)) |
| 2. BLK/YEL (PCM Power and Grounds) | 27. — |
| 3. YEL/BLK (PCM Power Supply) | 28. — |
| 4. BRN (PGM-FI System) | 29. YEL/GRN (Ignition System) |
| 5. BLK/RED (PGM-FI System) | 30. BLU/RED (Ignition System) |
| 6. YEL (PGM-FI System) | 31. GRN (PGM-FI System) |
| 7. BLU (PGM-FI System) | 32. GRN/RED (PGM-FI System) |
| 8. RED (PGM-FI System) | 33. GRN (ETCS (Electronic Throttle Control System)) |
| 9. WHT/BLU (PGM-FI System) | 34. GRN/WHT (PGM-FI System) |
| 10. BRN/WHT (A/T Controls) | 35. GRN/RED (PGM-FI System) |
| 11. BLK/RED (Ignition System) | 36. YEL/RED (PGM-FI System) |
| 12. BRN/WHT (Ignition System) | 37. RED (PGM-FI System) |
| 13. BLU (PGM-FI System) | 38. BLU (PGM-FI System) |
| 14. RED/BLU (PGM-FI System) | 39. GRN/YEL (VTEC System) |
| 15. RED (PGM-FI System) | 40. BLK (G101) |
| 16. WHT (PGM-FI System) | 41. BRN/YEL (G101) |
| 17. RED/BLK (ETCS (Electronic Throttle Control System)) | 42. BLK/YEL (PCM Power and Grounds) |
| 18. BLU (ETCS (Electronic Throttle Control System)) | 43. — |
| 19. WHT/BLK (Intake Air System) | 44. BLU/RED (PGM-FI System) |
| 20. BLU/WHT (VTEC System) | 45. BLU (PGM-FI System) |
| 21. GRN/RED (A/T Controls) | 46. YEL (PGM-FI System) |
| 22. WHT/BLU (Ignition System) | 47. — |
| 23. BRN (Ignition System) | 48. — |
| 24. RED/WHT (PGM-FI System) | 49. — |
| 25. GRN (PGM-FI System) | |

[Pin Numbering](#)[Circuit Index](#)

