

Условное обозначение:

A0	Color code key
F4	Load compartment fuse and relay box
F4f56	Fuse 56
F4f58	Fuse 58
N3/10	ME-SFI [ME] control unit
N93	Central gateway control unit
U12	Valid for left-hand drive vehicles
U13	Valid for right-hand drive vehicles
U151	Valid for engine 113
U152	Valid for engine 156
U475	Valid for M 272
U882	Valid for engine 629
W15/1	Ground (right footwell)
W15/2	Ground (left footwell)
W15/2	Ground (left footwell)
W15/2	Ground (left footwell)
X11/4	Data link connector
X11/4	Data link connector
X11/4	Data link connector
Z204/4	Circuit 31 right footwell voltage distributor connector
Z204/5	Circuit 31 left footwell voltage distributor connector (1)
Z204/5	Circuit 31 left footwell voltage distributor connector (1)
Z35/12	CAN D low connector sleeve
Z35/13	CAN D high connector sleeve
Z6/47	Ground (W15/2) connector sleeve

Позиция:

- 4L
- 6L
- 2L
- 15L
- 19L
- 11E
- 11E
- 13B
- 20D
- 20D
- 17D
- 12H
- 13G
- 8L
- 10G
- 4A
- 12A
- 19A
- 12L
- 12L
- 9L
- 22F
- 21F
- 8G



