



Address:
Postal address:
Phone: code4bin@gmail.com
Fax:
E-mail: code4bin@gmail.com

Mechanic:
Date: 01.11.2023
Car licence no:
VIN:
Mileage:
Vehicle: Iveco - Daily V - 2012

Fault codes

Engine electronics

DTC Description

No fault codes

72264

- Speed sensor on cardan joint
- CAN line error
- Intermittent

Battery voltage	12,60 Volt
Coverage driven length	611430,43 Km
DCL:Warm up cycle to delete the fault	40
Engine revolutions	0,00 Rpm
First registration	
FLC:Number of after-run to turn on the EOBD/EDC light	0
Frequency counter	227 Times
HLC:Number of after-run to switch off EOBD/EDC light	0
Injected fuel quantity	0,00 mg/stroke
Last registration	
Operation time	0 min
Vehicle speed	0,00 Km/h

100064(P1000)

- Coolant fluid pressure
- Incoherent sensor behavior
- Intermittent

Battery voltage	12,12 Volt
Coverage driven length	611430,43 Km
DCL:Warm up cycle to delete the fault	40
Engine revolutions	0,00 Rpm

531A(P0053)	First registration	
	FLC: Number of after-run to turn on the EOBD/EDC light	0
	Frequency counter	5 Times
	HLC: Number of after-run to switch off EOBD/EDC light	0
	Injected fuel quantity	0,00 mg/stroke
	Last registration	
	Operation time	0 min
	Vehicle speed	0,00 Km/h
	- Lambda sensor temperature	
	- A value below threshold has been detected	
	- Intermittent	
	Battery voltage	14,26 Volt
	Coverage driven length	611452,11 Km
	DCL: Warm up cycle to delete the fault	40
13001(P0130)	Engine revolutions	2677,50 Rpm
	First registration	
	FLC: Number of after-run to turn on the EOBD/EDC light	2
	Frequency counter	12 Times
	HLC: Number of after-run to switch off EOBD/EDC light	3
	Injected fuel quantity	49,50 mg/stroke
	Last registration	
	Operation time	641 min
	Vehicle speed	115,66 Km/h
	- Lambda sensor connection	
	- Open circuit on pin "nernst" of sensor	
	- Intermittent	
	Battery voltage	14,30 Volt
	Coverage driven length	614642,70 Km
	DCL: Warm up cycle to delete the fault	40
	Engine revolutions	2176,00 Rpm
	First registration	
	FLC: Number of after-run to turn on the EOBD/EDC light	3
	Frequency counter	1 Times
	HLC: Number of after-run to switch off EOBD/EDC light	0
	Injected fuel quantity	46,00 mg/stroke
	Last registration	
	Operation time	6 min

	Vehicle speed	73,88 Km/h
11662(P0116)	- Coolant temperature sensor, dynamic test was not plausible - A not plausible value has been detected compared to the engine working - Intermittent	
	Battery voltage	14,16 Volt
	Coverage driven length	616151,89 Km
	DCL:Warm up cycle to delete the fault	40
	Engine revolutions	1261,00 Rpm
	First registration	
	FLC:Number of after-run to turn on the EOBD/EDC light	3
	Frequency counter	1 Times
	HLC:Number of after-run to switch off EOBD/EDC light	0
	Injected fuel quantity	24,00 mg/stroke
	Last registration	
	Operation time	2 min
	Vehicle speed	7,58 Km/h

Brake (ESP/BSM - ABS9 / ASR9 / ESP9 - BSM)

DTC	Description
	No fault codes

405129	- SAS (Steering angle sensor) on VDB - Invalid signal - Inactive	
	Battery voltage, first occurrence	14,35 V
	Battery voltage, last occurrence	14,35 V
	Engine speed, first occurrence	1652 Rpm
	Engine speed, last occurrence	1774 Rpm
	Occurrence counter	35
	Vehicle speed, first occurrence	18 Km/h
	Vehicle speed, last occurrence	62 Km/h

Brake (ESP/BSM - ABS9 / ASR9 / ESP9 - BSM) (after last fault code deletion)

DTC	Description
	No fault codes

DTC	Description
	No fault codes

Multifunction (Body computer - Body computer marelli - BCM)

DTC	Description														
900715	<ul style="list-style-type: none"> - Turn light left - Short circuit to battery or open - Inactive 														
	<table> <tr> <td>Battery voltage, first occurrence</td><td>14,30 V</td></tr> <tr> <td>Battery voltage, last occurrence</td><td>12,30 V</td></tr> <tr> <td>Engine speed, first occurrence</td><td>791 Rpm</td></tr> <tr> <td>Engine speed, last occurrence</td><td>0 Rpm</td></tr> <tr> <td>Occurrence counter</td><td>109</td></tr> <tr> <td>Vehicle speed, first occurrence</td><td>20 Km/h</td></tr> <tr> <td>Vehicle speed, last occurrence</td><td>0 Km/h</td></tr> </table>	Battery voltage, first occurrence	14,30 V	Battery voltage, last occurrence	12,30 V	Engine speed, first occurrence	791 Rpm	Engine speed, last occurrence	0 Rpm	Occurrence counter	109	Vehicle speed, first occurrence	20 Km/h	Vehicle speed, last occurrence	0 Km/h
Battery voltage, first occurrence	14,30 V														
Battery voltage, last occurrence	12,30 V														
Engine speed, first occurrence	791 Rpm														
Engine speed, last occurrence	0 Rpm														
Occurrence counter	109														
Vehicle speed, first occurrence	20 Km/h														
Vehicle speed, last occurrence	0 Km/h														
D73E87	<ul style="list-style-type: none"> - DTM (digital tachograph module) on VDB - Missing message - Inactive 														
	<table> <tr> <td>Battery voltage, first occurrence</td><td>12,85 V</td></tr> <tr> <td>Battery voltage, last occurrence</td><td>12,60 V</td></tr> <tr> <td>Engine speed, first occurrence</td><td>793 Rpm</td></tr> <tr> <td>Engine speed, last occurrence</td><td>754 Rpm</td></tr> <tr> <td>Occurrence counter</td><td>3</td></tr> <tr> <td>Vehicle speed, first occurrence</td><td>0 Km/h</td></tr> <tr> <td>Vehicle speed, last occurrence</td><td>2 Km/h</td></tr> </table>	Battery voltage, first occurrence	12,85 V	Battery voltage, last occurrence	12,60 V	Engine speed, first occurrence	793 Rpm	Engine speed, last occurrence	754 Rpm	Occurrence counter	3	Vehicle speed, first occurrence	0 Km/h	Vehicle speed, last occurrence	2 Km/h
Battery voltage, first occurrence	12,85 V														
Battery voltage, last occurrence	12,60 V														
Engine speed, first occurrence	793 Rpm														
Engine speed, last occurrence	754 Rpm														
Occurrence counter	3														
Vehicle speed, first occurrence	0 Km/h														
Vehicle speed, last occurrence	2 Km/h														
D70387	<ul style="list-style-type: none"> - IPC (instrument control panel) on B CAN - Missing message - Inactive 														
	<table> <tr> <td>Battery voltage, first occurrence</td><td>12,70 V</td></tr> <tr> <td>Battery voltage, last occurrence</td><td>12,70 V</td></tr> <tr> <td>Engine speed, first occurrence</td><td>0 Rpm</td></tr> <tr> <td>Engine speed, last occurrence</td><td>0 Rpm</td></tr> <tr> <td>Occurrence counter</td><td>1</td></tr> <tr> <td>Vehicle speed, first occurrence</td><td>0 Km/h</td></tr> <tr> <td>Vehicle speed, last occurrence</td><td>0 Km/h</td></tr> </table>	Battery voltage, first occurrence	12,70 V	Battery voltage, last occurrence	12,70 V	Engine speed, first occurrence	0 Rpm	Engine speed, last occurrence	0 Rpm	Occurrence counter	1	Vehicle speed, first occurrence	0 Km/h	Vehicle speed, last occurrence	0 Km/h
Battery voltage, first occurrence	12,70 V														
Battery voltage, last occurrence	12,70 V														
Engine speed, first occurrence	0 Rpm														
Engine speed, last occurrence	0 Rpm														
Occurrence counter	1														
Vehicle speed, first occurrence	0 Km/h														
Vehicle speed, last occurrence	0 Km/h														
90AA4A	<ul style="list-style-type: none"> - Configuration check failed - Incorrect component installed - Inactive 														

	Battery voltage, first occurrence	12,65 V
	Battery voltage, last occurrence	12,65 V
	Engine speed, first occurrence	0 Rpm
	Engine speed, last occurrence	0 Rpm
	Occurrence counter	1
	Vehicle speed, first occurrence	0 Km/h
	Vehicle speed, last occurrence	0 Km/h
900815	- Turn light right	
	- Short circuit to battery or open	
	- Inactive	
	Battery voltage, first occurrence	14,10 V
	Battery voltage, last occurrence	14,45 V
	Engine speed, first occurrence	775 Rpm
	Engine speed, last occurrence	796 Rpm
	Occurrence counter	4
	Vehicle speed, first occurrence	3 Km/h
	Vehicle speed, last occurrence	0 Km/h